

DS-K3Y220(L)X Series Flap Barrier

User Manual

Legal Information

About this Document

- This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
- The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of the Document at the Hikvision website (<u>https://www.hikvision.com</u>). Unless otherwise agreed, Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as "Hikvision") makes no warranties, express or implied.
- Please use the Document with the guidance and assistance of professionals trained in supporting the Product.

About this Product

- This product can only enjoy the after-sales service support in the country or region where the purchase is made.
- If the product you choose is a video product, please scan the following QR code to obtain the "Initiatives on the Use of Video Products", and read it carefully.



Acknowledgment of Intellectual Property Rights

- Hikvision owns the copyrights and/or patents related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties.
- Any part of the Document, including text, pictures, graphics, etc., belongs to Hikvision. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.
- **HIKVISION** and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.
- Other trademarks and logos mentioned are the properties of their respective owners.

LEGAL DISCLAIMER

• TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS DOCUMENT AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR

IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.

- YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.
- YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.
- IN THE EVENT OF ANY CONFLICTS BETWEEN THIS DOCUMENT AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Data Protection

- To protect data, the development of Hikvision Products incorporates privacy by design principles. For example, for Products with facial recognition features, biometrics data is stored in your Products with encryption method; for fingerprint Products, only fingerprint template will be saved, which is impossible to reconstruct a fingerprint image.
- As a data controller/processor, you may process personal data, including collection, storage, use, processing, disclosure, deletion, etc. You are advised to pay attention to and comply with applicable laws and regulations related to the protection of personal data, including without limitation, conducting security controls to safeguard personal data, such as, implementing reasonable administrative and physical security controls, conduct periodic reviews and the assessments of the effectiveness of your security controls.

© Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.

Regulatory Information

FCC Information

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC compliance: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Conditions

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.

2. This device must accept any interference received, including interference that may cause undesired operation.

EU Conformity Statement



This product and - if applicable - the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the EMC Directive 2014/30/EU, RE Directive 2014/53/EU, the RoHS Directive 2011/65/EU



2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recyclethis.info



2006/66/EC (battery directive): This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see:www.recyclethis.info

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radioexempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

COMPLIANCE NOTICE

The thermal series products might be subject to export controls in various countries or regions, including without limitation, the United States, European Union, United Kingdom and/or other member countries of the Wassenaar Arrangement. Please consult your professional legal or compliance expert or local government authorities for any necessary export license requirements if you intend to transfer, export, re-export the thermal series products between different countries.

Safety Instruction

These instructions are intended to ensure that user can use the product correctly to avoid danger or property loss.

The precaution measure is divided into Dangers and Cautions:

Dangers: Neglecting any of the warnings may cause serious injury or death.

Cautions: Neglecting any of the cautions may cause injury or equipment damage.

\triangle	\triangle
	Cautions: Follow these precautions to prevent potential injury or material damage.

A Danger:

- In the use of the product, you must be in strict compliance with the electrical safety regulations of the nation and region.
- The equipment must be connected to an earthed mains socket-outlet.
- Shock hazard! Disconnect all power sources before maintenance.
- Do not touch the bare metal contacts of the inlets after the circuit breaker is turned off. Electricity still exists.
- *indicates hazardous live and the external wiring connected to the terminals requires installation by an instructed person.*
- Keep body parts away from fan blades. Disconnect the power source during servicing.
- Keep body parts away from motors. Disconnect the power source during servicing.
- To prevent possible hearing damage, do not listen at high volume levels for long periods.
- All the electronic operation should be strictly compliance with the electrical safety regulations, fire prevention regulations and other related regulations in your local region.
- Do not connect several devices to one power adapter as adapter overload may cause over-heat or fire hazard.
- Please make sure that the power has been disconnected before you wire, install or dismantle the device.

If the top caps should be open and the device should be powered on for maintenance, make sure:

- 1. Power off the fan to prevent the operator from getting injured accidentally.
- 2. Do not touch bare high-voltage components.
- 3. Make sure the switch's wiring sequence is correct after maintenance.
- Please make sure that the power has been disconnected before you wire, install or dismantle the device.
- When the product is installed on wall or ceiling, the device shall be firmly fixed.
- If smoke, odors or noise rise from the device, turn off the power at once and unplug the power cable, and then please contact the service center.

• Do not ingest battery, Chemical Burn Hazard.

This product contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death. Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

- If the product does not work properly, please contact your dealer or the nearest service center. Never attempt to disassemble the device yourself. (We shall not assume any responsibility for problems caused by unauthorized repair or maintenance.)
- Operation of this equipment in a residential environment could cause radio interference.
- The device do not support the PoE network switch. Connecting with the PoE network switch may damage the control board.

A Cautions:

- The equipment shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the equipment.
- Ensure correct wiring of the terminals for connection to an AC mains supply.
- The equipment has been designed, when required, modified for connection to an IT power distribution system.
- + identifies the positive terminal(s) of equipment which is used with, or generates direct current.
 + identifies the negative terminal(s) of equipment which is used with, or generates direct current.
- No naked flame sources, such as lighted candles, should be placed on the equipment.
- This equipment is suitable for mounting on concrete or other non-combustible surface only.
- Install the equipment according to the instructions in this manual.
- To prevent injury, this equipment must be securely attached to the floor/wall in accordance with the installation instructions.
- The main element of the turnstile is stainless steel, which is rustless (antioxidant) and corrosion resistant (The anti corrosion ability in the medium of acid, alkali, and salt). In order to keep the stainless steel from being oxidized or corroded, you should clean and care the turnstile surface periodically.

The instructions and tips for maintaining the turnstile are as follows:


- Select different stainless steel types according to the variety of the environments. You can select 304 stainless steel for common circumstances and 316 stainless steel for the scenarios of seasides and chemical plants.
- Keep the device surface clean and dry.
- Use non-woven cloth and ethyl alcohol to clean the dirt on the device surface.
- Use sourcing pad (do not use mesh cleaning ball) to clean the rust on the device surface by following the wire drawing on the stainless steel. And then use non-woven cloth and stainless steel cleaner to wipe the device surface.
- Clean and maintain the device by using non-woven cloth and stainless steel cleaner periodically. It is suggest to clean the device every month in common circumstances and every week for severe environments (seaside and chemical plants for instance.

- Do not drop the device or subject it to physical shock, and do not expose it to high electromagnetism radiation. Avoid the equipment installation on vibrations surface or places subject to shock (ignorance can cause equipment damage).
- Do not place the device in extremely hot (refer to the specification of the device for the detailed operating temperature), cold, dusty or damp locations, and do not expose it to high electromagnetic radiation.
- The device cover for indoor use shall be kept from rain and moisture.
- Exposing the equipment to direct sun light, low ventilation or heat source such as heater or radiator is forbidden (ignorance can cause fire danger).
- Do not aim the device at the sun or extra bright places. A blooming or smear may occur otherwise (which is not a malfunction however), and affecting the endurance of sensor at the same time.
- Please use the provided glove when open up the device cover, avoid direct contact with the device cover, because the acidic sweat of the fingers may erode the surface coating of the device cover.
- Please use a soft and dry cloth when clean inside and outside surfaces of the device cover, do not use alkaline detergents.
- Please keep all wrappers after unpack them for future use. In case of any failure occurred, you need to return the device to the factory with the original wrapper. Transportation without the original wrapper may result in damage on the device and lead to additional costs.
- Improper use or replacement of the battery may result in hazard of explosion. Replace with the same or equivalent type only. Dispose of used batteries according to the instructions provided by the battery manufacturer.
- Biometric recognition products are not completely applicable to anti-spoofing environments. If you require a higher security level, use multiple authentication modes.
- Do not stay in the lane when the device is rebooting.
- RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.
- SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.
- The instructions shall require connection of the equipment protective earthing conductor to the installation protective earthing conductor.

Available Models

Product Name	Model	Description
Flap Barrier	DS-K3Y220LX-L1	Left Pedestal 1
	DS-K3Y220LX-L2	Left Pedestal 2
	DS-K3Y220LX-M1	Middle Pedestal 1
	DS-K3Y220LX-M2	Middle Pedestal 2
	DS-K3Y220LX-R	Right Pedestal
	DS-K3Y220X-L1	Left Pedestal 1
	DS-K3Y220X-L2	Left Pedestal 2
	DS-K3Y220X-M1	Middle Pedestal 1
	DS-K3Y220X-M2	Middle Pedestal 2
	DS-K3Y220X-R	Right Pedestal

You can follow the picture below to select pedestals:



Contents

Chapter 1 Overview 1
1.1 Introduction 1
1.2 Main Features 2
Chapter 2 System Wiring 3
Chapter 3 Installation
Chapter 4 General Wiring
4.1 Components Introduction
4.2 Wiring 10
4.3 Terminal Description 11
4.3.1 General Wiring 11
4.3.2 Main Lane Control Board Terminal Description 12
4.3.3 Sub Lane Control Board Terminal Description 13
4.3.4 Access Control Board Terminal Description 14
4.3.5 Main Optional Board Terminal Description (Optional)
4.3.6 Sub Optional Board Terminal Description (Optional)
4.3.7 Card Reader Board Terminal Description 19
4.3.8 RS-485 Wiring 21
4.3.9 RS-232 Wiring 22
4.3.10 Alarm Input Wiring 22
4.3.11 Exit Button Wiring 23
Chapter 5 Device Settings via Button 24
5.1 Configuration via Button 25
5.2 Keyfob Pairing 27
5.2.1 Pair Keyfob via Button 27
5.2.2 Pair Keyfob via DIP Switch 28
5.3 Initialize Device


Chapter 6 Activation
6.1 Activate via SADP 31
6.2 Activate Device via iVMS-4200 Client Software 32
6.3 Activate via Web Browser 33
Chapter 7 Operation via Web Browser 34
7.1 Login 34
7.2 Overview
7.3 Person Management 35
7.4 Search Event 37
7.5 Configuration
7.5.1 View Device Information 39
7.5.2 Set Time
7.5.3 Set DST 40
7.5.4 Change Administrator's Password 40
7.5.5 Online Users 40
7.5.6 View Device Arming/Disarming Information 41
7.5.7 Network Settings 41
7.5.8 Event Linkage 43
7.5.9 Access Control Settings 44
7.5.10 Turnstile 49
7.5.10 TUTTISUIE
7.5.11 Card Settings
7.5.11 Card Settings 53
7.5.11 Card Settings 53 7.5.12 Set Privacy Parameters 54
7.5.11 Card Settings537.5.12 Set Privacy Parameters547.5.13 Upgrade and Maintenance54
7.5.11 Card Settings537.5.12 Set Privacy Parameters547.5.13 Upgrade and Maintenance547.5.14 Device Debugging55
7.5.11 Card Settings537.5.12 Set Privacy Parameters547.5.13 Upgrade and Maintenance547.5.14 Device Debugging557.5.15 Component Status55

8.1 Configuration Flow of Client Sof	ware 59
8.2 Device Management	59
8.2.1 Add Device	60
8.2.2 Reset Device Password	
8.2.3 Manage Added Devices	
8.3 Group Management	
8.3.1 Add Group	
8.3.2 Import Resources to Group	
8.4 Person Management	
8.4.1 Add Organization	65
8.4.2 Import and Export Person	dentify Information65
8.4.3 Get Person Information fro	m Access Control Device 68
8.4.4 Issue Cards to Persons in B	atch 69
8.4.5 Report Card Loss	69
8.4.6 Set Card Issuing Parameter	
8.4.6 Set Card Issuing Parameter 8.5 Configure Schedule and Templat	s 70
8.4.6 Set Card Issuing Parameter 8.5 Configure Schedule and Templat 8.5.1 Add Holiday	s 70 e 71
8.4.6 Set Card Issuing Parameter 8.5 Configure Schedule and Templat 8.5.1 Add Holiday 8.5.2 Add Template	rs
 8.4.6 Set Card Issuing Parameter 8.5 Configure Schedule and Templat 8.5.1 Add Holiday 8.5.2 Add Template 8.6 Set Access Group to Assign Access 	rs
 8.4.6 Set Card Issuing Parameter 8.5 Configure Schedule and Templat 8.5.1 Add Holiday 8.5.2 Add Template 8.6 Set Access Group to Assign Acce 8.7 Configure Advanced Functions 	rs
 8.4.6 Set Card Issuing Parameter 8.5 Configure Schedule and Template 8.5.1 Add Holiday 8.5.2 Add Template 8.6 Set Access Group to Assign Acces 8.7 Configure Advanced Functions 8.7.1 Configure Device Parameter 	s
 8.4.6 Set Card Issuing Parameter 8.5 Configure Schedule and Template 8.5.1 Add Holiday 8.5.2 Add Template 8.6 Set Access Group to Assign Access 8.7 Configure Advanced Functions 8.7.1 Configure Device Parameter 8.7.2 Configure Device Parameter 	s
 8.4.6 Set Card Issuing Parameter 8.5 Configure Schedule and Template 8.5.1 Add Holiday 8.5.2 Add Template 8.6 Set Access Group to Assign Acces 8.7 Configure Advanced Functions 8.7.1 Configure Device Parameter 8.7.2 Configure Device Parameter 	rs
 8.4.6 Set Card Issuing Parameter 8.5 Configure Schedule and Template 8.5.1 Add Holiday 8.5.2 Add Template 8.6 Set Access Group to Assign Access 8.7 Configure Advanced Functions 8.7.1 Configure Device Parameter 8.7.2 Configure Device Parameter 8.8 Door Control 8.8.1 Control Door Status 	rs
 8.4.6 Set Card Issuing Parameter 8.5 Configure Schedule and Template 8.5.1 Add Holiday 8.5.2 Add Template 8.6 Set Access Group to Assign Access 8.7 Configure Advanced Functions 8.7.1 Configure Device Parameter 8.7.2 Configure Device Parameter 8.8 Door Control 8.8.1 Control Door Status 8.8.2 Check Real-Time Access Res 	s
 8.4.6 Set Card Issuing Parameter 8.5 Configure Schedule and Template 8.5.1 Add Holiday 8.5.2 Add Template 8.6 Set Access Group to Assign Access 8.7 Configure Advanced Functions 8.7.1 Configure Device Parameter 8.7.2 Configure Device Parameter 8.8 Door Control 8.8.1 Control Door Status 8.8.2 Check Real-Time Access Res 	rs 70 e 71 71 71 72 72 ss Authorization to Persons 73 75 75 ers 75 ers 81 82 83 ecords 84

Appendix B. Button Configuration Description	. 87
Appendix C. Event and Alarm Type	. 97
Appendix D. Table of Audio Index Related Content	. 98
Appendix E. Error Code Description	. 99
Appendix F. Communication Matrix and Device Command	100

Chapter 1 Overview

1.1 Introduction



The flap barrier with 4 IR lights is designed to detect unauthorized entrance or exit. By adopting the flap barrier integratedly with the access control system, person should authenticate to pass through the lane via swiping IC or ID card, scanning QR code, etc. It is widely used in attractions, stadiums, construction sites, residences, etc.

1.2 Main Features

- Control mode, free passing mode and prohibition mode selectable on both entering and exiting direction.
- The barrier will be locked or stop working when people are nipped
- Anti-forced-accessing The barrier will be locked automatically without open-barrier signal.
- Self-detection, Self-diagnostics, and automatic alarm
- Audible and visual alarm will be triggered when detecting intrusion, tailgating, reverse passing, and climbing over barrier
- LED indicates the entrance/exit and passing status
- Barrier is in free status when powered down; If the device is installed with lithium battery (optional), the barrier remains open when powered down
- Fire alarm passing When the fire alarm is triggered, the barrier will be open automatically for emergency evacuation
- Valid passing duration settings
 System will cancel the passing permission if a person does not pass through the lane within the valid passing duration
- Adjustable indicator brightness
- Bidirectional (Entering/Exiting) lane
 The barrier opening and closing speed can be configured according to the visitor flow
- TCP/IP network communication The communication data is specially encrypted to relieve the concern of privacy leak
- Permissions validation and anti-tailgating


Chapter 2 System Wiring

The preparation before installation and general wiring.

Steps

iNote

- The device should be installed on the concrete surface or other non-flammable surfaces.
- If the installation area is too close to the wall, make sure the distance between the pedestal and the wall should be no less than 20 mm, or you cannot open the pedestal's top panel.



• The dimension is as follows.




Figure 2-1 Dimension

- **1.** Draw a central line on the installation surface of the left or right pedestal.
- 2. Draw other parallel lines for installing the other pedestals.

iNote

The distance between the nearest two line is 853.5 mm.

3. Slot on the installation surface and dig installation holes. Put 6 expansion bolts of M12 × 150 for each pedestal.




Figure 2-2 Hole Position and System Wiring

4. Bury cables. Each lane buries 1 high voltage cable and 1 low voltage cable. For details, see the system wiring diagram of step 3.

iNote

- High voltage: AC power input Low voltage: interconnecting cable (communication cable and 24 V power cable) and network communication cable
- The supplied 24 V power cable length is 4 m and the communication cable length is 4 m.
- The suggested inner diameter of the low voltage conduit is larger than 30 mm.
- If you want to bury both of the AC power cord and the low voltage cable, the two cables should be in separated conduits to avoid interference.
- If more peripherals are required to connect, you should increase the conduit diameter or bury another conduit for the external cables.
- The external AC power cord should be double-insulated.
- The network cable must be CAT5e or the network cable has better performance.

Chapter 3 Installation






Figure 3-1 Screw Hole

iNote

Keep the disassembled components and make sure the accessories are intact.

- 2. Prepare for system wiring and installation. For details, see <u>System Wiring</u>.
- 3. Place the pedestal above the embedded expansion bolt. Unscrew and remove the maintenance door.
- 4. Secure the pedestal with 6 bolts (M12 \times 150) and reinstall the maintenance door.

Scan the QR Code to view the accessories introduction video.



Chapter 4 General Wiring

iNote

- When you should maintain or disassemble the high voltage modules, you should remove the entire high voltage modules and maintain it outside the turnstile. You should unplug the cables that connected to the peripherals before maintenance to avoid destroy of the device.
- When disassembling the high voltage module, you should disconnect the power to avoid injury.
- If only wiring is needed without maintenance, do not remove the high voltage modules.
- The switch and the main lane control board are already connected. The 14 AWG cable to connect between the AC electric supply and the switch should be purchased separately.
- 2 interconnecting cables are supplied: 24 V Power Cable and Communication Cable.
 24 V Power Cable: 5 m long, which is in the middle and right pedestal.
 Communication Cable: 4 m long, CAT5e, which is in the package of middle and right pedestal.

4.1 Components Introduction

By default, basic components of the turnstile are connected well. The pedestals can communicate by wiring the interconnecting cables. And the turnstile supports wiring the AC electric supply for the whole system's power supply.

iNote

The voltage fluctuation of the electric supply is between 100 VAC and 240 VAC, 50 to 60 Hz.

The picture displayed below describes the serial port on the entrance and exit direction. You should select access control board kit for further wiring.





Figure 4-1 UART Corresponded Interface

The picture displayed below describes the IR sending/receiving module and their corresponding number on the pedestal.



iNote

If the turnstile contains two lanes, standing at the entrance position, the IR modules on the left pedestal are the IR sending modules. The IR modules on the right pedestal are the IR receiving modules. The IR modules on the left side of the middle pedestal are the IR receiving modules, while the IR modules on the right side of the middle pedestal are the IR sending modules.

4.2 Wiring

Scan the QR code to view the wiring video.



4.3 Terminal Description

The lane controller contains main lane controller and sub lane controller, which controls the IR beams, motor, and other components' work.

4.3.1 General Wiring

The general wiring of lane control board, access control board and optional board.




Figure 4-3 General Wiring

iNote

- The power cable from power supply to the main lane control board has been connected. You will need to prepare the 14 AWG power cable to connect the AC power input to power supply.
- The supplied 2 interconnecting cables need connecting on-site:
- 1. 24 V power cable of 14 AWG. The cable is 4 m in length and put inside the right and middle pedestal at the exit.

2. CAT5e Communication cable. The cable is 4 m in length and put inside the package of the right/middle pedestal.

- The (1) and (2) or (3) and (4) refer to the two sides of a same board.
- Barrier opens at the entrance/exit: connect to BTN1/BTN2 and GND.

4.3.2 Main Lane Control Board Terminal Description

The main lane control board contains interconnecting interface, USB flash drive interface (reserved), access control board interface, fire input interface, exit button interface, 12 VDC output interface (reserved), 24 VDC input interface, fan interface, communication interface, encoder

interface, power supply interface for motor, supercapacitor interface, IR adaptor interface and light bar interface.

The picture displayed below is the main lane control board diagram.




Figure 4-4 Main Lane Control Board Terminals

4.3.3 Sub Lane Control Board Terminal Description

The sub lane control board contains interconnecting interface, USB flash drive interface (reserved), access control board interface, exit button interface, 12 VDC power output interface (reserved), 24 VDC power input interface, fan interface, communication interface, encoder interface, power supply interface for motor, supercapacitor interface, IR adaptor interface and light bar interface.

The picture displayed below is the sub lane control board diagram.





Figure 4-5 Sub Lane Control Board Terminals

4.3.4 Access Control Board Terminal Description

Access control board is mainly used for authority identification in places with high security levels such as public security or judicial place, external device accessing, and communication with the upper platform and lane controller.

DS-K3Y220(L)X Series Flap Barrier User Manual



iNote

- RS-485A corresponds to port 5 on web and is for QR code scanner connection by default; RS-485C corresponds to port 7 on web and is for card reader connection by default.
- The SOC and MCU serial port are for maintenance and debugging use only.
- Press the Reset button for 5 s and the device will start to restore to factory settings.
- The DIP switch is for study mode setting and keyfob paring. For detailed information about the DIP switch, see <u>DIP Switch</u>.

The wiring diagram of extended interface of access control board is shown as follows.




Figure 4-6 Wring Diagram of Extended Interface

4.3.5 Main Optional Board Terminal Description (Optional)

The loudspeaker board contains the sub-1G antenna interface, lane control board interface, loudspeaker interface, debugging port, Wiegand/exit button interface, 5 VDC output and communication interface.





Figure 4-7 Loudspeaker Board Terminal



4.3.6 Sub Optional Board Terminal Description (Optional)


Figure 4-8 Sub Optional Board Terminal

Sub Optional Board Terminal Description		
12 VDC Power Output	12VOUT	12 VDC Power Output
	GND	Grounding
Wiegand (Optional)/Exit Button	BZ (Reserved)	Card Reader Buzzer Control Output
	W1 (Reserved)	Wiegand Head Read Data Input Data1
	W0 (Reserved)	Wiegand Head Read Data Input Data0

Sub Optional Board Terminal Description		
	GND (Reserved)	Grounding
	BTN	Access to Exit Button
	GND	Grounding
RS-485/232	RS-485 B+	Corresponded to UART6
	RS-485 B-	Connected with QR Code Scanner
	RS-485 D+	Correspond to UART4
	RS-485 D-	Connected with Card Reader by Default
	RS-232 BT	Correspond to UART2
	RS-232 BR	Connected with Fingerprint Module by Default
	RS-232 CT	Reserved
	RS-232 CR	
5 VDC Power Output	5VOUT	5 VDC Power Output
	GND	Connected with Ground
Communication Interface	BUS2	Connected with Sub Lane Control Board
BUS Interface	BUS1 TO SUB	Connected with Sub Lane Control Board


4.3.7 Card Reader Board Terminal Description

The card reader board can be connected to the access control board via RS-485 interface.





4.3.8 RS-485 Wiring




iNote

- There are four RS-485 interfaces, which are for connecting ID card reader, IC card reader, QR code scanner, fingerprint and card reader, card recycler, text screen, fingerprint reader, and face recognition terminal. Take the wiring of RS-485 card reader as an example.
- For details about text screen, see *Configuring Screen Parameters* in *User Manual of iVMS-4200* AC Client Software.

4.3.9 RS-232 Wiring

iNote

There are three RS-232 interfaces (UART4, UART7, and UART8). UART7 and UART8 can connect QR code scanner, and card recycler, while UART4 can connect QR code scanner, card recycler, and face recognition terminal.



4.3.10 Alarm Input Wiring

On the main lane control board, you can wire the fire alarm input interface.





Figure 4-10 Remaining Open

4.3.11 Exit Button Wiring

The main and sub lane control board each has 1 button interface, which can be connected to exit button or face recognition device.



iNote

- The face recognition devices are powered via 12 VDC power output interface of the main and sub lane control board.
- Barrier open at the entrance: connect to BTN1 and GND.
- Barrier open at the exit: connect to BTN2 and GND.

Chapter 5 Device Settings via Button

You can configure the device via button on the main lane control board.


Function	Main Lane Control Board Only
Working Mode	
keyfob Pairing	Not support
Passing Mode	Configure via button
Memory Mode	Configure via button
Parameter Settings	
Barrier Opening Speed	Configure via button
Barrier Closing Speed	Configure via button
Card Reading on the Alarm Area	Configure via button
Enter Duration	Configure via button
Exit Duration	Configure via button
IR Sensing Duration	Configure via button
Intrusion Duration	Configure via button
Overstay Duration	Configure via button
Delay Time for Barrier Closing	Configure via button
Authentication on Free Passing	Configure via button
Volume Adjustment	Configure via button
Barrier Material	Configure via button
Barrier Length	Configure via button
Light Brightness	Configure via button
Restore to Default	Configure via button
Voice Prompt	
Climbing over Barrier	Not support
Reverse Passing	Not support
Exceeding Passing Duration	Not support
Intrusion Alarm	Not support


Function	Main Lane Control Board Only
Tailgating Alarm	Not support
Overstaying Alarm	Not support
Motor Inspection	Configure via button
Self-check Voice Prompt	Not support
Study Mode Voice Prompt	Not support

Refer to **Button Configuration Description** for detailed information.

5.1 Configuration via Button

Button Description





Exit Button

- Press to open the barrier from the entrance position.
- Double press to open the barrier from the exit position.

Parameter Configuration Button

- LEFT: Press to add 10 to configuration data.
- RIGHT: Press to add 1 configuration data.
- CANCEL: Return to the Level-1 menu, or exit Level-1 menu.
- OK: Confirm the settings, or enter configuration mode, or enter the Level-2 menu.

iNote

- Configuration No. is displayed by two digital tubes.
- Level-1 Menu: If the decimal point on the right is on, it indicates the Level-1 menu. The number represents the configuration No.
- Level-2 Menu: If the decimal point in the middle is on, it indicates the level-2 menu. The number represents the configuration No.

Button Configuration Procedure



Figure 5-2 Procedure

Steps:

- 1. Hold **OK** button for 3 s until one beep occurs. The device enter the configuration mode. Level 1 menu lights up. The display screen displays the configuration No. **1**.
- In the Level-1 menu, press LEFT (plus 10) and RIGHT (plus 1) to set the configuration No. Press OK to save settings and the enter the level-2 menu. Press CANCEL to exit the current menu, or conduct no operation for 5 s to cancel configuration and exit the current menu.
- 3. After enter the level 2 menu, press **LEFT** (plus 10) and **RIGHT** (plus 1) to set the parameters at your needs. Press **OK** to save the settings or press **CANCEL** to exit the current menu, or conduct no operation for 5 s to cancel configuration and exit the current menu.

iNote

- The configuration No. will display in a cycle.
- Each configuration No. refers to a function. For details about the configuration No. and its related function, see *Button Configuration Description*.

Example

If you want to pair keyfobs via the button. Hold **OK** for 3 s until you hear one beep. The device enters the configuration mode and the level 1 decimal point lights up. The display screen will display the No. **1**.

In the Level-1 menu, press **Right** (plus 1) to adjust the configuration No. to **2**. Press **OK** to save the settings and enter the Level-2 menu.

Press **Right** (plus 1) to adjust the configuration No. to **2**. Press **OK** to save the settings.

5.2 Keyfob Pairing

Pair keyfob via button or DIP switch.

5.2.1 Pair Keyfob via Button

Pair the keyfob to the device via button to open/close the barrier remotely.

Before You Start

Ask our technique supports or sales and purchase the keyfob.

Steps

iNote

- For details about button's operation, see Configuration via Button.
- For details about the configuration No. and its related function, see <u>Button Configuration</u>
 <u>Description</u>.
- For details about the keyfob operation instructions, see the keyfob's user manual.
- 1. Enter the keyfob pairing mode.
 - 1) Enter the configuration mode.

2) Set the configuration No. in Level-1 to 2. The device will enter the keyfob pairing mode.

- 3) Set the configuration No. in the Level-2 menu to **2**. The device will enter the keyfob pairing mode.
- 2. Hold the Close button for more than 10 seconds.

The keyfob's indicator will flash if the pairing is completed.

- **3.** Exit the keyfob pairing mode.
 - 1) Enter the configuration mode.
 - 2) Set the configuration No. in Level-1 to **2**. The device will enter the keyfob pairing mode.
 - 3) Set the configuration No. in the Level-2 menu to **1**. The device will exit the keyfob pairing mode.
- **4.** Reboot the device to take effect.

5.2.2 Pair Keyfob via DIP Switch

Pair the remote control to the device through DIP switch to open/close the barrier remotely.

Before You Start

Ask our technique supports or sales and purchase the keyfob.

Steps

- 1. Power off the turnstile.
- 2. Set the No.2 switch of the DIP Switch on the access control board to the ON side.




Figure 5-4 Enable Keyfob Paring Mode

- **3.** Power on the turnstile and it will enter the keyfob pairing mode.
- 4. Hold the Close button for more than 10 seconds.

The keyfob's indicator of the will flash twice if the pairing is completed.

5. Set the No.2 switch to the OFF side, and reboot the turnstile to take effect.

iNote

- Only one turnstile can pair the keyfob. If multiple turnstiles are in the pairing mode, the keyfob will select only one of them to pair.
- For details about DIP switch value and meaning, see **<u>DIP Switch Description</u>**.
- 6. Optional: Go to System → User → Keyfob User on the remote control page of the client software to delete the keyfob.

5.3 Initialize Device

Steps

1. Hold the initialization button on the access control board for 5 s.




Figure 5-5 Initialization Button Position

- 2. The device will start restoring to factory settings.
- 3. When the process is finished, the device will beep for 3 s.

ACaution

The initialization of the device will restore all the parameters to the default setting and all the device events are deleted.

∎Note

Make sure no persons are in the lane when powering on the device.

Chapter 6 Activation

You should activate the device before the first login. After powering on the device, the system will switch to Device Activation page.

Activation via the device, SADP tool and the client software are supported.

The default values of the device are as follows:

- The default IP address: 192.0.0.64
- The default port No.: 8000
- The default user name: admin

6.1 Activate via SADP

SADP is a tool to detect, activate and modify the IP address of the device over the LAN.

Before You Start

- Get the SADP software from the supplied disk or the official website <u>http://</u> <u>www.hikvision.com/en/</u>, and install the SADP according to the prompts.
- The device and the PC that runs the SADP tool should be within the same subnet.

The following steps show how to activate a device and modify its IP address. For batch activation and IP addresses modification, refer to *User Manual of SADP* for details.

Steps

- 1. Run the SADP software and search the online devices.
- 2. Find and select your device in online device list.
- 3. Input new password (admin password) and confirm the password.

Caution

STRONG PASSWORD RECOMMENDED-We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

iNote

Characters containing admin and nimda are not supported to be set as activation password.

4. Click Activate to start activation.

ID	- Device Type	Security	IPv4 Address	Port	Software Version	ID-4 Gateway	L HTTP Rest	I Desire Serial No.	
001	(n. energy)	Active	10.16.6.20	8000		10.16.6.254	80	DS-HUMIND-20127540413CH	
002	D5-6HE303-A	Active	10.16.6.21	8000	VLDBuild 1888.	10.16.6.254	80	DS ADMITS ADVANCED	0
003	DS-KONDOV-AU	Active	10.16.6.213	8000	VLL Rocket 1812-	10.16.6.254	N/A	D5-428528-428541287VE	
004	DS-15408-0425	Active	10.16.6.179	8000	VL0.536-abd 180-	10.16.6.254	N/A	Di contri i recelemente d	
005	DS-13408-018NG	Active	10.16.6.127	8000	V2.2 (build 1877	10.16.6.254	N/A	IN CASE CONCERNMENTS	The device is not activated.
005	UNKOWN DEVICE TYPE	Active	10.16.6.250	8000	VSA/Ibuild 1855	10.16.6.254	80	20141110001074801406798	
·] (007	%-2CD	20259940	4	Inactiv	e	1	192.0.0.64	You can modify the network parameters af
009	D5-13508%-047/420W	[^] Se	lect in	activ	e devic	e.	80	DS 202099-0404220404220	the device activation.
						nnu	t an	d confirm	New Password:
						mpu	t an	a co	Quara .
						pass			Strong Confirm Password:

Status of the device becomes Active after successful activation.

- 5. Modify IP address of the device.
 - 1) Select the device.
 - 2) Change the device IP address to the same subnet as your computer by either modifying the IP address manually or checking **Enable DHCP**.
 - 3) Input the admin password and click **Modify** to activate your IP address modification.

6.2 Activate Device via iVMS-4200 Client Software

For some devices, you are required to create the password to activate them before they can be added to the iVMS-4200 software and work properly.

Steps

iNote

This function should be supported by the device.

1. Enter the Device Management page.

- 2. Click on the right of **Device Management** and select **Device**.
- 3. Click Online Device to show the online device area.

The searched online devices are displayed in the list.

- 4. Check the device status (shown on Security Level column) and select an inactive device.
- 5. Click Activate to open the Activation dialog.
- 6. Create a password in the password field, and confirm the password.

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you change your password regularly, especially in the high security system, changing the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

iNote

Characters containing admin and nimda are not supported to be set as activation password.

7. Click OK to activate the device.

6.3 Activate via Web Browser

You can activate the device via the web browser.

Steps

1. Enter the device default IP address (192.0.0.64) in the address bar of the web browser, and press **Enter**.

iNote

Make sure the device IP address and the computer's should be in the same IP segment.

2. Create a new password (admin password) and confirm the password.

A Caution

STRONG PASSWORD RECOMMENDED-We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

iNote

Characters containing admin and nimda are not supported to be set as activation password.

3. Click Activate.

4. Edit the device IP address. You can edit the IP address via the SADP tool, the device, and the client software.

Chapter 7 Operation via Web Browser

7.1 Login

You can login via the web browser or the remote configuration of the client software.

iNote

Make sure the device is activated. For detailed information about activation, see Activation .

Login via Web Browser

Enter the device IP address in the address bar of the web browser and press **Enter** to enter the login page.

Enter the device user name and the password. Click Login.

Login via Remote Configuration of Client Software

Download and open the client software. After adding the device, click page to enter the Configuration page.

7.2 Overview

You can view the device component status, real-time event, person information, network status, basic information, and device capacity. You can also control the barrier remotely.

Device Component Status View More	Remote Control	Real-Time Event					View More
		Employee ID	Name	Card No.	Event Types	Time	Operation
	1.1			12	Event Input Alarm Recovered	2022-08-31 20:00:03	
			***		Event Input Alarm Recovered	2022-08-31 20:00:03	
	Entrance	S Unlock V	22.5	-	Device Powering On	2022-08-31 20:00:24	
		S Unlock ~			IP Address Conflicted	2022-08-31 20:00:25	220
				240	Lane Controller Offline	2022-08-31 20:00:28	
Operating normally.	Entrance	5 H		~	IP Address Conflicted	2022-08-31 20:01:25	
1 0 1	Exit	-	**		IP Address Conflicted	2022-08-31 20:02:25	
0			シ	Not Added			
Network Status	Basic	Information			Device Capacity		
Wired Network Connected		Model			L Perso	n 0 /100000	
		Serial No.			Card	0 /200000	
		Firmware Version					

Figure 7-1 Overview

Function Descriptions:

Device Component Status

You can check if the device is working properly. Click **View More** to view the detailed component status.

Remote Control

r/A/ℝ/ ₪

The door is opened/closed/remaining open/remaining closed.

Real-Time Event

You can view the event Employee ID, Name, Card No., Event Type, Time, and Operation. You can also click **View More** to enter the search conditions, including the event type, employee ID, the name, the card No., the start time, and the end time, and click **Search**. The results will be displayed on the right panel.

Person Information

You can view the added and not added information of person and card.

Network Status

You can view the connected and registered status of wired network, wireless network, ISUP and cloud service.

Basic Information

You can view the model, serial No. and firmware version.

Device Capacity

You can view the person and card capacity.

7.3 Person Management

Click **Add** to add the person's information, including the basic information, certificate, authentication and settings.

Basic Information	
*Employee ID	
Name	
Gender	Male Female Unknown
Person Type	Normal User Visitor Person in Blocklist
Long-Term Effective User	
Validity Period	2022-08-22 00:00:00 - 2032-08-21 23:59:59 🗎
Administrator	
Card	O Up to 50 cards can be supported.
	+ Add Card
	··
Authentication Settings	
Authentication Settings Authentication Type	• Same as Device O Custom

Figure 7-2 Add Person

Add Basic Information

Click **Person Management** \rightarrow **Add** to enter the Add Person page.

Add the person's basic information, including the employee ID, the person's name, the gender, and person type.

If you select Visitor as the person type, you can set the visit times.

Click **Save** to save the settings.

Set Permission Time

Click **Person Management** \rightarrow **Add** to enter the Add Person page.

Enable Long-Term Effective User, or set Validity Period and the person can only has the permission within the configured time period according to your actual needs. Click Save to save the settings.

Add Card

Click **Person Management** \rightarrow **Add** to enter the Add Person page. Click **Add Card**, enter the **Card No.** and select the **Property**, and click **OK** to add the card.

iNote

Up to 50 cards can be added.

Click **Save** to save the settings.

Authentication Settings

Click **Person Management** \rightarrow **Add** to enter the Add Person page. Set **Authentication Type** as **Same as Device** or **Custom**. Click **Save** to save the settings.

7.4 Search Event

Click **Event Search** to enter the Search page.

Employee ID	
Name	
Card No.	
Start Time	
2022-02-28 00:00:00	(-)
End Time	
2022-02-28 23:59:59	(=) []]

Figure 7-3 Search Event

Enter the search conditions, including the event type, the employee ID, the name, the card No., the start time, and the end time, and click **Search**.

The event types contain access control event and ID card event. If you choose to search for ID card event, you will not need to enter the employee ID, the name, or the card No.

The results will be displayed on the right panel.

7.5 Configuration

7.5.1 View Device Information

Click **Configuration** \rightarrow **System** \rightarrow **System** Settings \rightarrow **Basic Information** to enter the configuration page.

You can view the device name, language, model, serial No., version, IO input, IO output, local RS-485, alarm input, alarm output, and device capacity, etc.

You can change **Device Name** and click **Save**.

7.5.2 Set Time

Set the device's time.

$Click \text{ Configuration} \rightarrow System \rightarrow System \text{ Settings} \rightarrow Time \text{ Settings} .$

Time Zone	(GMT+08:00) Beijing, Urumqi, Singapore, Perth v							~	
me Synchronization mode	NTP Manual								
Set Time	2015-01-01 00:36:49							3	Sync With Computer T
DST									
DST									
	April ~	First	~	Sunday	~	02	~		
DST	April ~ October ~	First Last	~	Sunday	× ×	02	× ×		

Figure 7-4 Time Settings

Click **Save** to save the settings after the configuration.

Time Zone

Select the device located time zone from the drop-down list.

Time Sync.

NTP

You should set the NTP server's IP address, port No., and interval.

Manual

By default, the device time should be synchronized manually. You can set the device time manually or check **Sync. with Computer Time** to synchronize the device time with the computer's time.

Server Address Type/Server Address/NTP Port/Interval

You can set the server address type, server address, NTP port, and interval.

7.5.3 Set DST

Steps

- 1. Click Configuration → System → System Settings → Time Settings .
- 2. Enable DST.
- 3. Set the DST start time, end time and bias time.
- 4. Click Save to save the settings.

7.5.4 Change Administrator's Password

Steps

- 1. Click Configuration → System → User Management .
- **2.** Click ∠ .
- 3. Enter the old password and create a new password.
- **4.** Confirm the new password.
- 5. Click Save.

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you change your password regularly, especially in the high security system, changing the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

7.5.5 Online Users

The information of users logging into the device is shown.

Go to **Configuration** \rightarrow **System** \rightarrow **User Management** \rightarrow **Online Users** to view the list of online users.

7.5.6 View Device Arming/Disarming Information

View device arming type and arming IP address.

Go to Configuration \rightarrow User Management \rightarrow Arming/Disarming Information .

You can view the device arming/disarming information. Click **Refresh** to refresh the page.

7.5.7 Network Settings

Set TCP/IP and port.

Set Basic Network Parameters

Click Configuration \rightarrow Network \rightarrow Network Settings \rightarrow TCP/IP.

Set the parameters and click **Save** to save the settings.

NIC Type

Select a NIC type from the drop-down list. By default, it is **Auto**.

DHCP

If uncheck the function, you should set the IPv4 address, IPv4 subnet mask, IPv4 default gateway, Mac address, and MTU.

If you check the function, the system will allocate the IPv4 address, IPv4 subnet mask, the IPv4 default gateway automatically.

DNS Server

Set the preferred DNS server and the Alternate DNS server according to your actual need.

Set Port Parameters

Set the HTTP, HTTPS, and HTTP Listening parameters.

Click Configuration → Network → Network Service → HTTP(S).

Enable		
	Enabling HTTP may cause security problems.	
HTTP Port		0
TTPS		
Enable		
HTTPS Port		0
TTP Listening		
TTP Listening Event Alarm IP Address/Domain *URL Port		

Figure 7-5 Network Service

HTTP

It refers to the port through which the browser accesses the device. For example, when the HTTP Port is modified to 81, you need to enter *http://192.0.0.65:81* in the browser for login.

HTTPS

Set the HTTPS for accessing the browser. Certificate is required when accessing.

HTTP Listening

The device can send alarm information to the event alarm IP address or domain name via HTTP protocol/HTTPS protocol. Edit the event alarm IP address or domain name, URL, port, and protocol.

iNote

The event alarm IP address or domain name should support the HTTP protocol/HTTPS protocol to receive the alarm information.

7.5.8 Event Linkage

Set linked actions for events.

Steps

1. Click **Configuration** → **Event** → **Basic Event** → **Event Linkage** to enter the page.

+ Add	Event Source		
Add New Event and Card Linkage	Linkage Type	Event Linkage Card Linkage	C Link Employee ID
	Event Types	Device Event \sim	No Memory Alarm for Unreporter \vee
	Linkage Action		
	Buzzer Linkage		
	Door Linkage		
	Linked Alarm Output		
		Save	

Figure 7-6 Event Linkage

- 2. Set event source.
 - If you choose Linkage Type as Event Linkage, you need to select event types from the dropdown list.
 - If you choose Linkage Type as Card Linkage, you need to enter the card No. and select the card reader.
 - If you choose Linkage Type as Employee ID Linkage, you need to enter the employee ID and select the card reader.
- **3.** Set linked action.

Linked Buzzer

Enable Linked Buzzer and select Start Buzzing or Stop Buzzing for the target event.

Linked Door

Enable Linked Door, check Door 1 or Door 2, and set the door status for the target event.

Linked Alarm Output

Enable Linked Alarm Output, check Alarm Output 1 or Alarm Output 2, and set the alarm output status for the target event.

7.5.9 Access Control Settings

Set Authentication Parameters

$Click \text{ Configuration} \rightarrow \textbf{Access Control} \rightarrow \textbf{Authentication Settings} \ .$

iNote

The functions vary according to different models. Refers to the actual device for details.

Terminal	Entrance Exit	
Terminal Type	Card	
Terminal Model	485Offline	
Enable Authentication Device		
Authentication	Card	~
Authentication Interval	0	s 🖒
() Alarm of Max. Failed Attempts		
Communication with Controller Ev	0	s 🗘
	Save	

Figure 7-7 Set Authentication Parameters

Click **Save** to save the settings after the configuration.

Terminal

Choose Entrance or Exit for settings.

Terminal Type/Terminal Model

Get terminal description. They are read-only.

Enable Authentication Device

Enable the authentication function.

Authentication

Select an authentication mode according to your actual needs from the drop-down list.

Authentication Interval

You can set the authentication interval of the same person when authenticating. The same person can only authenticate once in the configured interval. A second authentication will be failed.

Alarm of Max. Failed Attempts

Enable to report alarm when the card reading attempts reach the set value.

Max. Authentication Failed Attempts

Enable to report alarm when the card reading attempts reach the set value.

Communication with Controller Every

When the access control device cannot connect with the card reader for longer than the set time, the card reader will turn offline automatically.

iNote

The authentication interval value ranges from 2 s to 255 s.

Set Door Parameters

Click Configuration \rightarrow Access Control \rightarrow Door Parameters .

Door No. Door Name	Entrance	
Open Duration	8	s 📏
Exit Button Type	🔿 Remain Closed 🛛 💿 Remain Open	
oor Remain Open Duration with	10	min 🗘

Figure 7-8 Door Parameters Settings Page

Click **Save** to save the settings after the configuration.

Door No.

Select Entrance or Exit for settings.

Door Name

You can create a name for the door.

Open Duration

Set the door unlocking duration. If the door is not opened for the set time, the door will be locked.

iNote

The open duration ranges from 5 s to 60 s.

Exit Button Type

You can set the exit button as **Remain Open** or **Remain Closed** according to your actual needs. By default, it is **Remain Open**.

Door Remain Open Duration with First Person

Set the door open duration when first person is in. After the first person is authorized, it allows multiple persons access the door or other authentication actions.

iNote

The duration ranges from 1 s to 1440 s.

Serial Port Settings

Set serial port parameters.

Steps

1. Click Configuration → Access Control → Serial Port Configuration .

DS-K3Y220(L)X Series Flap Barrier User Manual

Serial Port Type	RS232
No.	1 v
Baud Rate	19200 ~
Data Bit	8
Stop Bit	
Parity	None Odd Parity Even Verification
Peripheral Type	○ Card Reader ○ Card Receiver ○ QR Code Scanner ● Disable
External Device Model	None
Peripheral Software Version	None
	Save

Figure 7-9 Serial Port Settings

- 2. Set the No., Baud Rate, Data Bit, Stop Bit and Parity.
- 3. Set the Peripheral Type as Card Reader, QR Code Scanner or Disable.
- **4.** You can view the serial port type, connected device model and peripheral software version.
- 5. Click Save.

Host Parameters

Set door contact settings and RS-485 protocol.

Steps

- **1.** Click **Configuration** → **Access Control** → **Host Parameter** to enter the page.
- 2. Set door contact.



You can set the door contact as **Door Open Status** or **Door Closed Status** according to your actual needs. By default, it is **Door Open Status**.

- 3. Set RS-485 protocol.
- 4. Click Save.

Set Terminal Parameters

Set the working mode.

Steps

1. Set the device working mode and remote verification.

Working Mode		
-	O Permission Free Mode ①	• Access Control Mode ①
Remote Verification		
(i) Remote Verification		
ID Card Verification Center	On Device	
Blocklist Authentication		
	Save	

Figure 7-10 Working Mode and Remote Verification

Permission Free Mode

The device will not verify the person's permission, but only the person's validity period. If the person is in the validity period, the barrier will open.

You can enable **Verify Credential Locally**. After enabling the function, the device will only verify the person's permission without the schedule template, etc.

Access Control Mode

The device works normally and will verify the person's permission to open the barrier.

Remote Verification

When authenticating, device uploads authentication information to the platform, and platform confirms whether to open the door or not.

Blocklist Authentication

When enabling the function, the device will check the whether the authenticating person is in the blocklist or not.

2. Click Save to complete terminal parameter settings.

7.5.10 Turnstile

Basic Parameters

Set turnstile basic parameters.

Steps

1. Click **Configuration** → **Turnstile** → **Basic Settings** to enter the page.

Channel Type	Swing Barrier	
Channel Model		
Barrier Material	Acrylic	~
Lane Width	900	~
Barrier Opening Speed	O	 5 🗘
Barrier Closing Speed	O	- 4
Working Status	Normal	
Passing Mode	General Passing Weekly Schedule	
Entrance	Controlled	~
Exit	Controlled	~
	Save	

Figure 7-11 Basic Parameters

- 2. View the Device Type, Device Model and Working Status.
- 3. Set Barrier Material, Lane Width, Barrier Opening Speed and Barrier Closing Speed.
- 4. Set the passing mode.
 - If you choose **General Passing**, you can select the barrier status for the entrance and exit from the drop-down list.

iNote

If you set barrier-free mode, the barrier remains open and will close when authentication fails.

```
- If you choose Weekly Schedule, you can set a weekly schedule for entrance and exit barriers. 5. Click Save.
```

keyfob

Set keyfob patameters.

Steps

```
1. Click Configuration \rightarrow Turnstile \rightarrow Keyfob to enter the page.
```

Working Status	Normal			
Working Mode	🔿 One-to-One 🖲 One-to-Many			
Keyfob	🕂 Add 🗴 Delete			
	Name	Serial No.	Remain Open Permission	Operation
	Save			

Figure 7-12 keyfob

- 2. View the keyfob working status.
- 3. Set Working Mode as One-to-One or One-to-Many.
- 4. Add keyfob.
 - 1) Click **Add** and the keyfob adding window will pop up.
 - 2) Enter the Name and Serial No..
 - 3) Check to enable **Remain Open Permission** at your actual needs.
 - 4) Click **OK** to add the keyfob.
- 5. Optional: Select a keyfob and click **Delete** to delete the keyfob.
- 6. Click Save.

IR Detector

Set IR detector.

Steps

1. Click **Configuration** \rightarrow **Turnstile** \rightarrow **IR Detector** to enter the page.

Inductive Mode (Entrance)	Single Triggered Criggered Simultaneously
Inductive Mode (Exit)	Single Triggered O Triggered Simultaneously
Custom IR Detector	Enable IR Emergency Mode () Enable Custom Anti-pinch for Door Closing ()
)	Save

Figure 7-13 IR Detector

- 2. Set the entrance and exit inductive mode as Single Triggered or Triggered Simultaneously.
- **3.** Set custom IR detector mode.

Enable IR Emergency Mode

If some IR beams do not work properly, you can shield those IR beams to restore the lane. But this action may hit person and cause injury.

Enable Custom Anti-pinch for Door Closing

Anti-pinch for door closing refers that the barrier will not close if the device has detected person in the lane. Only after the person walks out of the lane, the barrier will close. If you enable the function, you can shield parts of the IR beams for closing barrier in advance. But this action may hit person and cause injury.

4. Click Save.

People Counting

Set people counting.

Steps

```
1. Click Configuration \rightarrow Turnstile \rightarrow People Counting to enter the page.
```

People Counting			
Device Offline People Counting			
Person Statistics Type) Invalid	Passing Detection	O Authentication Number
People Counting	Clear		
	Save		

Figure 7-14 People Counting

- 2. Check to enable People Counting.
- 3. Enable Device Offline People Counting at your actual needs.
- 4. Select People Counting Type as Invalid, Passing Detection or Authentication Number.
- 5. Optional: Click clear to clear all the people counting information.

Other Settings

Set other parameters.

Steps

1. Click **Configuration** \rightarrow **Turnstile** \rightarrow **Other Settings** to enter the page.

2. Set Alarm Output Duration.

iNote

The alarm output duration ranges from 0 s to 3599 s.

- 3. Set Temperature Unit.
- 4. Check to enable Do Not Open Barrier When Lane is Not Clear.
- 5. Drag the block or enter the value to adjust the light board brightness.
- **6.** Set the alarm buzzer beeping duration, door closing delay time, intrusion duration, overstaying duration and IR obstructed duration.
- 7. Check to enable Memory Mode at your actual needs.

iNote

Multiple cards presenting for multiple person passing is allowable when enabling the memory mode. When the passing person's number exceeds the card presenting number, or after the latest person passing with no other person passing within the door open duration, the door will close automatically.

8. Choose the control mode.

Soft Mode

The barrier will be closed after the person has passed through the barrier when there are tailing, forced accessing, etc.

Guard Mode

The barrier will be closed immediately when there are tailgating, forced accessing, etc. **9.** Set the fire input type.

- **10.** Click to enable **Motor Self-Test** and choose the main lane or sub lane to start motor self-testing.
- 11. Click Save.

7.5.11 Card Settings

Set Card Security

Click Configuration \rightarrow Card Settings \rightarrow Card Type to enter the settings page.

Set the parameters and click **Save**.

Enable NFC Card

In order to prevent the mobile phone from getting the data of the access control, you can enable NFC card to increase the security level of the data.

Enable M1 Card

Enable M1 card and authenticating by presenting M1 card is available.

M1 Card Encryption

Sector

M1 card encryption can improve the security level of authentication.

Enable the function and set the encryption sector. By default, Sector 13 is encrypted. It is recommended to encrypt sector 13.

Enable EM Card

Enable EM card and authenticating by presenting EM card is available.

iNote

If the peripheral card reader supports presenting EM card, the function is also supported to enable/disable the EM card function.

Enable CPU Card

Enable CPU card and authenticating by presenting CPU card is available.

CPU Card Read Content

After enable the CPU card content reading function, the device can read the CPU card content.

Enable FeliCa Card

The device can read the data from FeliCa card when enabling the FeliCa card function.

Set Card Authentication Parameters

Set the card reading content when authenticate via card on the device.

Go to Configuration \rightarrow Card Settings \rightarrow Card NO. Authentication Settings .

Select a card authentication mode and enable reversed card No. at your actual needs. Click Save.

7.5.12 Set Privacy Parameters

Set the event storage type.

Go to Configuration → Security → Privacy Settings

The event storage type is overwriting by default. The earliest 5% events will be deleted when the system detects the stored events has been over 95% of the full space.

7.5.13 Upgrade and Maintenance

Reboot device, restore device parameters, and upgrade device version.

Reboot Device

 $\mathsf{Click} \text{ Maintenance and Security} \rightarrow \mathsf{Maintenance} \rightarrow \mathsf{Restart} \ .$

Click **Restart** to reboot the device.

Upgrade

Click Maintenance and Security → Maintenance → Upgrade .

Select an upgrade type from the drop-down list. Click and select the upgrade file from your local PC. Click **Upgrade** to start upgrading.

If the device has been connected to Hik-Connect and network, when there is a new installation package in Hik-Connect, you can click **Upgrade** after Online Update to upgrade the device system.

iNote

Do not power off during the upgrading.

Restore Parameters

 $\mathsf{Click}\ \mathbf{Maintenance}\ \mathbf{and}\ \mathbf{Security}\ \boldsymbol{\rightarrow}\ \mathbf{Maintenance}\ \boldsymbol{\rightarrow}\ \mathbf{Backup}\ \mathbf{and}\ \mathbf{Reset}\ .$

Restore All

All parameters will be restored to the factory settings. You should activate the device before usage.

Restore

The device will restore to the default settings, except for the device IP address and the user information.

Import and Export Parameters

 $\mathsf{Click}\ \mathbf{Maintenance}\ \mathbf{and}\ \mathbf{Security}\ \boldsymbol{\rightarrow}\ \mathbf{Maintenance}\ \boldsymbol{\rightarrow}\ \mathbf{Backup}\ \mathbf{and}\ \mathbf{Reset}\ .$

Export

Click **Export** to export the device parameters.

iNote

You can import the exported device parameters to another device.

Import

Click 🛅 and select the file to import. Click **Import** to start import configuration file.

7.5.14 Device Debugging

You can set device debugging parameters.

Steps

1. Click Maintenance and Security \rightarrow Maintenance \rightarrow Device Debugging .

2. You can set the following parameters.

Enable SSH

To raise network security, disable SSH service. The configuration is only used to debug the device for the professionals.

Print Log

You can click **Export** to export log.

7.5.15 Component Status

You can view the main lane and sub lane status.

Main Lane Status

Device Component

You can view the status of the access control board, lane control board, extended interface board, and arrow light board.

Peripheral

You can view the status of the RS-485 card reader.

Temperature

You can view the pedestal temperature.

Movement

You can view the working status of motor encoder.

Sub Lane Status

Device Component

You can view the status of the access control board and arrow light board.

Peripheral

You can view the status of the RS-485 card reader.

Movement

You can view the working status of motor encoder.

Others

Passing Mode

You can view the entrance and exit mode.

IR Detector Status

You can view the status of each pair of the IR beam sensors.

Input and Output Status

You can view the status of the event input, alarm output and fire alarm.

Other Status

You can view the status of the barrier and the keyfob receiving module.

7.5.16 Log Query

You can search and view the device logs.

Go to Maintenance and Security \rightarrow Maintenance \rightarrow Log .

Set the major and minor type of the log type. Set the start time and end time for searching, and click **Search**.

The results will be displayed below, which including the No., time, the major type the minor type, the channel No., the local/remote user information, the remote host IP, etc.

7.5.17 Certificate Management

It helps to manage the server/client certificates and CA certificate.

iNote

The function is only supported by certain device models.

Create and Install Self-signed Certificate

Steps

- 1. Go to Maintenance and Security → Security → Certificate Management .
- 2. In the Certificate Files area, select a Certificate Type from the drop-down list.
- 3. Click Create.
- 4. Input certificate information.
- 5. Click OK to save and install the certificate.

The created certificate is displayed in the **Certificate Details** area.

The certificate will be saved automatically.

- 6. Download the certificate and save it to an asking file in the local computer.
- 7. Send the asking file to a certification authority for signature.
- 8. Import the signed certificate.
 - 1) Select a certificate type in the **Import Passwords** area, and select a certificate from the local, and click **Install**.
 - 2) Select a certificate type in the **Import Communication Certificate** area, and select a certificate from the local, and click **Install**.

Install Other Authorized Certificate

If you already has an authorized certificate (not created by the device), you can import it to the device directly.

Steps

- **1.** Go to Maintenance and Security \rightarrow Security \rightarrow Certificate Management .
- 2. In the Import Passwords and Import Communication Certificate areas, select certificate type and upload certificate.
- 3. Click Install.

Install CA Certificate

Before You Start

Prepare a CA certificate in advance.

Steps

- **1.** Go to Maintenance and Security \rightarrow Security \rightarrow Certificate Management .
- 2. Create an ID in the Import CA Certificate area.

iNote

The input certificate ID cannot be the same as the existing ones.

4. Click Install.

^{3.} Upload a certificate file from the local.

Chapter 8 Client Software Configuration

8.1 Configuration Flow of Client Software

Follow the flow diagram below to configure on the client software.




Figure 8-1 Flow Diagram of Configuration on Client Software

8.2 Device Management

The client supports managing access control devices and video intercom devices.

Example

You can control entrance & exit and manage attendance after adding access control devices to the client; you can perform video intercom with the indoor stations and door stations.

8.2.1 Add Device

The client provides three device adding modes including by IP/domain, IP segment, and ISUP protocol. The client also supports importing multiple devices in a batch when there are large amount of devices to be added.

Add Device by IP Address or Domain Name

If you know the IP address or domain name of the device to add, you can add devices to the client by specifying the IP address (or domain name), user name, password, etc.

Steps

- 1. Enter Device Management module.
- 2. Click **Device** tab on the top of the right panel.

The added devices are displayed on the right panel.

- 3. Click Add to open the Add window, and then select IP/Domain as the adding mode.
- 4. Enter the required information.

Name

Create a descriptive name for the device. For example, you can use a nickname that can show the location or feature of the device.

Address

The IP address or domain name of the device.

Port

The devices to add share the same port number. The default value is **8000**.

iNote

For some device types, you can enter **80** as the port No. This function should be supported by the device.

User Name

Enter the device user name. By default, the user name is *admin*.

Password

Enter the device password.

Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you change your password regularly, especially in the high security system, changing the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

5. Optional: Check **Transmission Encryption (TLS)** to enable transmission encryption using TLS (Transport Layer Security) protocol for security purpose.

iNote

- This function should be supported by the device.
- If you have enabled Certificate Verification, you should click **Open Certificate Directory** to open the default folder, and copy the certificate file exported from the device to this default directory to strengthen the security. See for details about enabling certificate verification.
- You can log into the device to get the certificate file by web browser.
- 6. Check Synchronize Time to synchronize the device time with the PC running the client after adding the device to the client.
- **7. Optional:** Check **Import to Group** to create a group by the device name, and import all the channels of the device to this group.

Example

For access control device, its access points, alarm inputs/outputs, and encoding channels (if exist) will be imported to this group.

- 8. Finish adding the device.
 - Click Add to add the device and back to the device list page.
 - Click Add and New to save the settings and continue to add other device.

Import Devices in a Batch

You can add multiple devices to the client in a batch by entering the device parameters in a predefined CSV file.

Steps

- 1. Enter the Device Management module.
- 2. Click Device tab on the top of the right panel.
- 3. Click Add to open the Add window, and then select Batch Import as the adding mode.
- 4. Click Export Template and then save the pre-defined template (CSV file) on your PC.
- **5.** Open the exported template file and enter the required information of the devices to be added on the corresponding column.

iNote

For detailed description of the required fields, refer to the introductions in the template.

Adding Mode

Enter **0** or **1** or **2**.

Address

Edit the address of the device.

Port

Enter the device port number. The default port number is 80.

User Name

Enter the device user name. By default, the user name is *admin*.

Password

Enter the device password.

Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you change your password regularly, especially in the high security system, changing the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

Import to Group

Enter **1** to create a group by the device name. All the channels of the device will be imported to the corresponding group by default. Enter **0** to disable this function.

- 6. Click and select the template file.
- **7.** Click **Add** to import the devices.

8.2.2 Reset Device Password

If you forgot the password of the detected online devices, you can reset the device password via the client.

Steps

- 1. Enter Device Management page.
- 2. Click Online Device to show the online device area.

All the online devices sharing the same subnet will be displayed in the list.

3. Select the device from the list and click $prescript{2}$ on the Operation column.

4. Reset the device password.

- Click **Generate** to pop up the QR Code window and click **Download** to save the QR code to your PC. You can also take a photo of the QR code to save it to your phone. Send the picture to our technical support.

i Note

For the following operations for resetting the password, contact our technical support.

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you change your password regularly, especially in the high security system, changing the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

8.2.3 Manage Added Devices

After adding devices to device list, you can manage the added devices including editing device parameters, remote configuration, viewing device status, etc.

Edit Device	Click 📓 to edit device information including device name, address, user name, password, etc.
Delete Device	Check one or more devices, and click Delete to delete the selected devices.
Remote Configuration	Click log to set remote configuration of the corresponding device. For details, refer to the user manual of device.
View Device Status	Click 🔄 to view device status, including door No., door status, etc. I Note For different devices, you will view different information about device status.
View Online User	Click 🖾 to view the details of online user who access the device, including user name, user type, IP address and login time.
Refresh Device Information	Click 🔁 to refresh and get the latest device information.

Table 8-1 Manage Added Devices

8.3 Group Management

The client provides groups to manage the added resources in different groups. You can group the resources into different groups according to the resources' locations.

Example

For example, on the 1st floor, there mounted 16 doors, 64 alarm inputs, and 16 alarm outputs. You can organize these resources into one group (named 1st Floor) for convenient management. You can control door status, and do some other operations of the devices after managing the resources by groups.

8.3.1 Add Group

You can add group to organize the added device for convenient management.

Steps

- 1. Enter the Device Management module.
- **2.** Click **Device Management** \rightarrow **Group** to enter the group management page.
- 3. Create a group.
 - Click Add Group and enter a group name as you want.
 - Click **Create Group by Device Name** and select an added device to create a new group by the name of the selected device.

iNote

The resources (such as alarm inputs/outputs, access points, etc.) of this device will be imported to the group by default.

8.3.2 Import Resources to Group

You can import the device resources (such as alarm inputs/outputs, access points, etc.) to the added group in a batch.

Before You Start

Add a group for managing devices. Refer to <u>Add Group</u>.

Steps

- **1.** Enter the Device Management module.
- **2.** Click **Device Management** \rightarrow **Group** to enter the group management page.
- **3.** Select a group from the group list and select the resource type as **Access Point**, **Alarm Input**, **Alarm Output**, etc.
- 4. Click Import.
- 5. Select the thumbnails/names of the resources in the thumbnail/list view.

iNote

You can click or for the selected resource display mode to thumbnail view or to list view. 6. Click Import to import the selected resources to the group.

8.4 Person Management

You can add person information to the system for further operations such as access control, video intercom, time and attendance, etc. You can manage the added persons such as issuing cards to them in a batch, importing and exporting person information in a batch, etc.

8.4.1 Add Organization

You can add an organization and import person information to the organization for effective management of the persons. You can also add a surbodinate organization for the added one.

Steps

- 1. Enter Person module.
- 2. Select a parent organization in the left column and click Add in the upper-left corner to add an organization.
- 3. Create a name for the added organization.

i Note		
Up to 10 levels of organizations can be added.		
4. Optional: Perform the following operation(s).		

Edit Organization	Hover the mouse on an added organization and click 🜌 to edit its name.
Delete	Hover the mouse on an added organization and click $ imes$ to delete it.
Organization	i Note
	 The lower-level organizations will be deleted as well if you delete an organization.
	 Make sure there is no person added under the organization, or the organization cannot be deleted.
Show Persons in Sub Organization	Check Show Persons in Sub Organization and select an organization to show persons in its sub organizations.

8.4.2 Import and Export Person Identify Information

You can import the information and pictures of multiple persons to the client software in a batch. Meanwhile, you can also export the person information and pictures and save them in your PC.

Import Person Information

You can enter the information of multiple persons in a predefined template (CSV/Excel file) to import the information to the client in a batch.

Steps

- 1. Enter the Person module.
- **2.** Select an added organization in the list, or click **Add** in the upper-left corner to add an organization and then select it.
- 3. Click Import to open the Import panel.
- 4. Select Person Information as the importing mode.
- 5. Click Download Template for Importing Person to download the template.
- 6. Enter the person information in the downloaded template.

iNote

- If the person has multiple cards, separate the card No. with semicolon.
- Items with asterisk are required.
- By default, the Hire Date is the current date.
- **7.** Click to select the CSV/Excel file with person information from local PC.
- 8. Click Import to start importing.

iNote

- If a person No. already exists in the client's database, delete the existing information before importing.
- You can import information of no more than 2,000 persons.

Import Person Pictures

After importing face pictures for the added persons to the client, the persons in the pictures can be identified by an added face recognition terminal. You can either import person pictures one by one, or import multiple pictures at a time according to your need.

Before You Start

Be sure to have imported person information to the client beforehand.

Steps

- 1. Enter the Person module.
- **2.** Select an added organization in the list, or click **Add** in the upper-left corner to add an organization and then select it.
- 3. Click Import to open the Import panel and check Face.
- **4. Optional:** Enable **Verify by Device** to check whether face recognition device managed in the client can recognize the face in the photo.
- 5. Click is to select a face picture file.

iNote

- The (folder of) face pictures should be in ZIP format.
- Each picture file should be in JPG format and should be no larger than 200 KB.
- Each picture file should be named as "Person ID_Name". The Person ID should be the same with that of the imported person information.
- 6. Click Import to start importing.

The importing progress and result will be displayed.

Export Person Information

You can export the added persons' information to local PC as a CSV/Excel file.

Before You Start

Make sure you have added persons to an organization.

Steps

- **1.** Enter the Person module.
- **2. Optional:** Select an organization in the list.

iNote

All persons' information will be exported if you do not select any organization.

- 3. Click Export to open the Export panel.
- 4. Check Person Information as the content to export.
- 5. Check desired items to export.
- 6. Click Export to save the exported file in CSV/Excel file on your PC.

Export Person Pictures

You can export face picture file of the added persons and save in your PC.

Before You Start

- Make sure you have added persons and their face pictures to an organization.
- Make sure you have enabled the **Export Person Information** function to display the **Export** button. See for details.

Steps

- **1.** Enter the Person module.
- 2. Optional: Select an organization in the list.

i Note

All persons' face pictures will be exported if you do not select any organization.

3. Click Export on the top menu bar.

4. Enter the super user name and password for verification.

The Export panel is displayed.

- 5. Check Face as the content to export.
- 6. Click Export and set an encryption key to encrypt the exported file.

iNote

- The exported file is in ZIP format.
- The exported face picture is named as "Person ID_Name_0" ("0" is for a full-frontal face).

8.4.3 Get Person Information from Access Control Device

If the access control device has been configured with person information (including person details, fingerprint, and issued card information), you can get the person information from the added device and import them to the client for further operations.

Steps

iNote

- If the person name stored in the device is empty, the person name will be filled with the issued card No. after importing to the client.
- Persons will be **Male** by default.
- If the card number or person ID (employee ID) stored on the device already exists in the client database, the person with this card number or person ID will not be imported to the client.

1. Enter Person module.

- 2. Select an organization to import the persons.
- 3. Click Get from Device.
- **4.** Select an added access control device or the enrollment station from the drop-down list.

iNote

If you select the enrollment station, you should click **Login**, and enter IP address, port No., user name and password of the device.

5. Select the Getting Mode.

iNote

The getting mode varies according to different devices. The access control device supports getting the person information by employee ID. Up to 5 employee IDs can be specified each time.

6. Click Import to start importing the person information to the client.

iNote

Up to 2,000 persons and 5,000 cards can be imported.

The person information, including person details, person's fingerprint information (if configured), and the linked cards (if configured), will be imported to the selected organization.

8.4.4 Issue Cards to Persons in Batch

The client provides a convenient way to issue cards to multiple persons in a batch.

Steps

- 1. Enter Person module.
- 2. Click Batch Issue Cards.

All the added persons with no card issued will be displayed in the right panel.

- **3. Optional:** Enter key words (name or person ID) in the input box to filter the person(s) that need issuing cards.
- **4. Optional:** Click **Settings** to set the card issuing parameters. For details, refer to *Issue a Card by Local Mode*.
- **5.** Click **Initialize** to initialize the card enrollment station or card reader to make it ready for issuing cards.
- 6. Click the Card No. column and enter the card number.
 - Place the card on the card enrollment station.
 - Swipe the card on the card reader.
 - Manually enter the card number and press the Enter key.

The person(s) in the list will be issued with card(s).

8.4.5 Report Card Loss

If the person lost his/her card, you can report the card loss so that the card's related access authorization will be inactive.

Steps

- 1. Enter Person module.
- 2. Select the person you want to report card loss for and click Edit to open the Edit Person window.
- **3.** In the **Credential** \rightarrow **Card** panel, click **Card** on the added card to set this card as lost card.

After reporting card loss, the access authorization of this card will be invalid and inactive. Other person who gets this card cannot access the doors by swiping this lost card.

4. Optional: If the lost card is found, you can click 🚮 to cancel the loss.

After cancelling card loss, the access authorization of the person will be valid and active.

5. If the lost card is added in one access group and the access group is applied to the device already, after reporting card loss or cancelling card loss, a window will pop up to notify you to apply the changes to the device. After applying to device, these changes can take effect on the device.

8.4.6 Set Card Issuing Parameters

The client provides two modes for reading a card's number: via card enrollment station or via the card reader of the access control device. If a card enrollment station is available, connect it to the PC running the client by USB interface or COM, and place the card on the card enrollment to read the card number. If not, you can also swipe the card on the card reader of the added access control device to get the card number. As a result, before issuing a card to one person, you need to set the card issuing parameters including the issuing mode and related parameters.

When adding a card to one person, click Settings to open the Card Issuing Settings window.

Local Mode: Issue Card by Card Enrollment Station

Connect a card enrollment station to the PC running the client. You can place the card on the card enrollment station to get the card number.

Card Enrollment Station

Select the model of the connected card enrollment station

iNote

Currently, the supported card enrollment station models include DS-K1F100-D8, DS-K1F100-M, DS-K1F100-D8E, and DS-K1F180-D8E.

Card Type

This field is only available when the model is DS-K1F100-D8E or DS-K1F180-D8E.

Select the card type as EM card or IC card according to the actual card type.

Serial Port

It is only available when the model is DS-K1F100-M.

Select the COM the card enrollment station connects to.

Buzzing

Enable or disable the buzzing when the card number is read successfully.

Card No. Type

Select the type of the card number according to actual needs.

M1 Card Encryption

This field is only available when the model is DS-K1F100-D8, DS-K1F100-D8E, or DS-K1F180-D8E.

If the card is M1 card, and if you need to enable the M1 Card Encryption function, you should enable this function and select the sector of the card to encrypt.

Remote Mode: Issue Card by Card Reader

Select an access control device added in the client and swipe the card on its card reader to read the card number.

8.5 Configure Schedule and Template

You can configure the template including holiday and week schedule. After setting the template, you can adopt the configured template to access groups when setting the access groups, so that the access group will take effect in the time durations of the template.

iNote

For access group settings, refer to Set Access Group to Assign Access Authorization to Persons .

8.5.1 Add Holiday

You can create holidays and set the days in the holidays, including start date, end date, and holiday duration in one day.

Steps

iNote

You can add up to 64 holidays in the software system.

- **1.** Click Access Control \rightarrow Schedule \rightarrow Holiday to enter the Holiday page.
- 2. Click Add on the left panel.
- 3. Create a name for the holiday.
- **4. Optional:** Enter the descriptions or some notifications of this holiday in the Remark box.
- 5. Add a holiday period to the holiday list and configure the holiday duration.

iNote

Up to 16 holiday periods can be added to one holiday.

- 1) Click Add in the Holiday List field.
- 2) Drag the cursor to draw the time duration, which means in that duration of time, the configured access group is activated.

iNote

Up to 8 time durations can be set to one holiday period.

3) **Optional:** Perform the following operations to edit the time durations.

- Move the cursor to the time duration and drag the time duration on the timeline bar to the desired position when the cursor turns to Markov .
- Click the time duration and directly edit the start/end time in the appeared dialog.
- Move the cursor to the start or the end of time duration and drag to lengthen or shorten the time duration when the cursor turns to
- 4) **Optional:** Select the time duration(s) that need to be deleted, and then click in the Operation column to delete the selected time duration(s).
- 5) **Optional:** Click **m** in the Operation column to clear all the time duration(s) in the time bar.

- 6) **Optional:** Click 📉 in the Operation column to delete this added holiday period from the holiday list.
- 6. Click Save.

8.5.2 Add Template

Template includes week schedule and holiday. You can set week schedule and assign the time duration of access authorization for different person or group. You can also select the added holiday(s) for the template.

Steps

iNote

You can add up to 255 templates in the software system.

1. Click Access Control → Schedule → Template to enter the Template page.

iNote

There are two default templates: All-Day Authorized and All-Day Denied, and they cannot be edited or deleted.

All-Day Authorized

The access authorization is valid in each day of the week and it has no holiday.

All-Day Denied

The access authorization is invalid in each day of the week and it has no holiday.

- 2. Click Add on the left panel to create a new template.
- **3.** Create a name for the template.
- **4.** Enter the descriptions or some notification of this template in the Remark box.
- 5. Edit the week schedule to apply it to the template.
 - 1) Click Week Schedule tab on the lower panel.
 - 2) Select a day of the week and draw time duration(s) on the timeline bar.

iNote

Up to 8 time duration(s) can be set for each day in the week schedule.

- 3) **Optional:** Perform the following operations to edit the time durations.
 - Move the cursor to the time duration and drag the time duration on the timeline bar to the desired position when the cursor turns to Markovica.
 - Click the time duration and directly edit the start/end time in the appeared dialog.
 - Move the cursor to the start or the end of time duration and drag to lengthen or shorten the time duration when the cursor turns to
- 4) Repeat the two steps above to draw more time durations on the other days of the week.
- **6.** Add a holiday to apply it to the template.

iNote

Up to 4 holidays can be added to one template.

- 1) Click Holiday tab.
- 2) Select a holiday in the left list and it will be added to the selected list on the right panel.
- 3) Optional: Click Add to add a new holiday.

iNote

For details about adding a holiday, refer to Add Holiday .

- 4) **Optional:** Select a selected holiday in the right list and click is to remove the selected one, or click **Clear** to clear all the selected holiday(s) in the right list.
- 7. Click Save to save the settings and finish adding the template.

8.6 Set Access Group to Assign Access Authorization to Persons

After adding the person and configuring the person's credentials, you can create the access groups to define which person(s) can get access to which door(s) and then apply the access group to the access control device to take effect.

Before You Start

- Add person to the client.
- Add access control device to the client and group access points. For details, refer to <u>Group</u>
 <u>Management</u>.
- Add template.

Steps

When the access group settings are changed, you need to apply the access groups to the devices again to take effect. The access group changes include changes of template, access group settings, person's access group settings, and related person details (including card number, fingerprint, face picture, linkage between card number and fingerprint, linkage between card number and fingerprint, card password, card effective period, etc).

1. Click **Access Control** → **Authorization** → **Access Group** to enter the Access Group interface.

- 2. Click Add to open the Add window.
- 3. In the Name text field, create a name for the access group as you want.
- 4. Select a template for the access group.

iNote

You should configure the template before access group settings. Refer to <u>Configure Schedule</u> <u>and Template</u> for details.

- 5. In the left list of the Select Person field, select person(s) to assign access authority.
- 6. In the left list of the Select Access Point field, select door(s), door station(s) or floor(s) for the selected persons to access.

7. Click Save.

You can view the selected person(s) and the selected access point(s) on the right side of the interface.

+ Add 1	🕯 Delete 🛛 Apply All to	Device 🔍 A	pply Changes to	Device	P	Person				
	Name	Template	Status	Operation		TheName 🔶	SerialNumb	r Org	nization	
	Access Group 2	All-Day Auth				Jane		New	Organizati	on
O	Access Group 1	All-Day Auth	To be Appli			Mike		New	Organizati	on
	Access Group 3	All-Day Auth	To be Appli							
						Total 2 Records Access Point Access Point Door1_Access o Door2 Access o	÷ ontrol host	Group N Access c		/1Page(s)
						Door2_Access o				
						Total 2 Record(/1Page(s)

Figure 8-2 Display the Selected Person(s) and Access Point(s)

- **8.** After adding the access groups, you need to apply them to the access control device to take effect.
 - 1) Select the access group(s) to apply to the access control device.
 - 2) Click **Apply All to Devices** start applying all the selected access group(s) to the access control device or door station.
 - 3) Click Apply All to Devices or Apply Changes to Devices.

Apply All to Devices

This operation will clear all the existed access groups of the selected devices and then apply the new access group to the device.

Apply Changes to Devices

This operation will not clear the existed access groups of the selected devices and only apply the changed part of the selected access group(s) to the device(s).

4) View the applying status in the Status column or click **Applying Status** to view all the applied access group(s).

iNote

You can check **Display Failure Only** to filter the applying results.

The selected persons in the applied access groups will have the authorization to enter/exit the selected doors/door stations with their linked card(s) or fingerprints.

9. Optional: Click **a** to edit the access group if necessary.

∎Note

If you change the persons' access information or other related information, you will view the prompt **Access Group to Be Applied** on the right corner of the client.

You can click the prompt to apply the changed data to the device. You can select either **Apply Now** or **Apply Later**.




Figure 8-3 Data Synchronization

8.7 Configure Advanced Functions

You can configure the advanced functions of access control to meet some special requirements in different scene.

iNote

- For the card related functions (the type of access control card), only the card(s) with access group applied will be listed when adding cards.
- The advanced functions should be supported by the device.
- Hover the cursor on the Advanced Function, and then Click at to customize the advanced function(s) to be displayed.

8.7.1 Configure Device Parameters

After adding the access control device, you can configure the parameters of access control device, access control points.

Configure Parameters for Access Control Device

After adding the access control device, you can configure its parameters, including overlaying user information on picture, uploading pictures after capturing, saving captured pictures, etc.

Before You Start

Add access control device to the client.

Steps

1. Click Access Control → Advanced Function → Device Parameters .

iNote

If you can not find Device Parameter in the Advanced Function list, hover the cursor on the Advanced Function, and then Click in the Select the Device Parameter to be displayed.

- 2. Select an access device to show its parameters on the right page.
- 3. Turn the switch to ON to enable the corresponding functions.

iNote

- The displayed parameters may vary for different access control devices.
- Some of the following parameters are not listed in the Basic Information page, click **More** to edit the parameters.

Enable NFC

If enable the function, the device can recognize the NFC card. You can present NFC card on the device.

Enable M1 Card

If enable the function, the device can recognize the M1 card. You can present M1 card on the device.

Enable EM Card

If enable the function, the device can recognize the EM card. You can present EM card on the device.

Enable CPU Card

Reserved. If enable the function, the device can recognize the CPU card. You can present CPU card on the device.

Enable ID Card

Reserved. If enable the function, the device can recognize the ID card. You can present ID card on the device.

4. Click OK.

5. Optional: Click **Copy to**, and then select the access control device(s) to copy the parameters in the page to the selected device(s).

Configure Parameters for Door

After adding the access control device, you can configure its access point door parameters.

Steps

- **1.** Click Access Control → Advanced Function → Device Parameter .
- 2. Select an access control device on the left panel, and then click is to show the doors or floors of the selected device.
- **3.** Select a door or floor to show its parameters on the right page.
- **4.** Edit the door or floor parameters.

iNote

S

The displayed parameters may vary for different access control devices.

Name

Edit the card reader name as desired.

Exit Button Type

You can set the exit button as remaining closed or remaining open. Usually, it is remaining open.

Open Duration

After swiping the normal card and relay action, the time for locking the door starts working.

Door Left Open Timeout Alarm

The alarm can be triggered if the door has not been closed in a configured time period. If it is set as 0, no alarm will be triggered.

Super Password

The specific person can open the door by inputting the super password.

5. Some of the following parameters are not listed in the Basic Information page, click **Advanced** to edit the parameters.

Duress Code

The door can open by inputting the duress code when there is duress. At the same time, the client can report the duress event.

Dismiss Code

Create a dismiss code which can be used to stop the buzzer of the card reader (by entering the dismiss code on the keypad).

iNote

- The duress code, super code, and dismiss code should be different.
- The duress code, super password, and the dismiss code should be different from the authentication password.
- The length of duress code, super password, and the dismiss code is according the device, usually it should contains 4 to 8 digits.

6. Click OK.

7. Optional: Click **Copy to** , and then select the door(s) to copy the parameters in the page to the selected doors(s).

iNote

The door's status duration settings will be copied to the selected door(s) as well.

Configure Parameters for Card Reader

After adding the access control device, you can configure its card reader parameters.

Steps

- **1.** Click Access Control → Advanced Function → Device Parameter .
- 2. In the device list on the left, click to expand the door, select a card reader and you can edit the card reader's parameters on the right.
- **3.** Edit the card reader basic parameters in the Basic Information page.

iNote

The displayed parameters may vary for different access control devices. There are part of parameters listed as follows. Refer to the user manual of the device for more details.

Name

Edit the card reader name as desired.

Minimum Card Swiping Interval

If the interval between card swiping of the same card is less than the set value, the card swiping is invalid. You can set it as 0 to 255.

Alarm of Max. Failed Attempts

Enable to report alarm when the card reading attempts reach the set value.

Card Reader Type/Card Reader Description

Get card reader type and description. They are read-only.

4. Optional: Some of the following parameters are not listed in the Basic Information page, click **Advanced** to edit the parameters.

Enable Card Reader

If enabling the function, user can present card on the card reader. If disabling the function, the card reader for entrance cannot be used.

OK LED Polarity/Error LED Polarity/Buzzer Polarity

Set OK LED Polarity/Error LED Polarity/Buzzer LED Polarity of main board according to the card reader parameters. Generally, adopts the default settings.

Buzzing Time

Set the card reader buzzing time. The available time ranges from 0 to 5,999s. 0 represents continuous buzzing.

Max. Interval When Entering PWD

When you inputting the password on the card reader, if the interval between pressing two digits is larger than the set value, the digits you pressed before will be cleared automatically.

Tampering Detection

Enable the anti-tamper detection for the card reader.

Communicate with Controller Every

When the access control device cannot connect with the card reader for longer than the set time, the card reader will turn offline automatically.

Fingerprint Recognition Level

Select the fingerprint recognition level in the drop-down list.

- 5. Click OK.
- **6. Optional:** Click **Copy to**, and then select the card reader(s) to copy the parameters in the page to the selected card reader(s).

Configure Parameters for Alarm Output

After adding the access control device, if the device links to alarm outputs, you can configure the parameters.

Before You Start

Add access control device to the client, and make sure the device supports alarm output.

Steps

- 1. Click Access Control → Advanced Function → Device Parameter to enter access control parameter configuration page.
- 2. In the device list on the left, click to expand the door, select an alarm input and you can edit the alarm input's parameters on the right.
- 3. Set the alarm output parameters.

Name

Edit the card reader name as desired.

Alarm Output Active Time

How long the alarm output will last after triggered.

- 4. Click OK.
- 5. Optional: Set the switch on the upper right corner to ON to trigger the alarm output.

Configure Parameters for Lane Controller

After adding the lane controller to the client, you can configure its parameters for passing through the lane.

Steps

- Click Access Control → Advanced Function → Device Parameter to enter Parameter Settings page.
- **2.** In the device list on the left, select a lane controller and you can edit the lane controller's parameters on the right.
- 3. Edit the parameters.

Passing Mode

Select the controller which will control the barrier status of the device.

- If you select **According to DIP Settings**, the device will follow the lane controller's DIP settings to control the barrier. The settings on the software will be invalid.
- If you select **According to Door's Schedule Settings**, the device will follow the settings of the software to control the barrier. The DIP settings of the lane controller will be invalid.

Enable Free Passing Authentication

If you enable this function, when both entrance and exit's barrier mode is Remain Open, the pedestrians should authenticate each time passing through the lane. Or an alarm will be triggered.

Alarm Voice Prompt Time Duration

Set how long the audio will last, which is played when an alarm is triggered .

iNote

0 refers to the alarm audio will be played until the alarm is ended.

Temperature Unit

Select the temperature unit that displayed in the device status.

Motor Rotation Direction

Set the motor rotation as **Clockwise** or **Anticlockwise**. The motor rotation direction is the barrier's open direction.

iNote

- For single pedestal scenario, the motor rotation direction should set as **Clockwise**.
- For multiple pedestals scenario, standing at the entrance, the motor rotation direction from right to left should set as: **Clockwise**, **Anticlockwise**, **Clockwise**, etc. respectively.

Lightboard Brightness

Set the lightboard brightness.

Barrier Material

Select the material of the barrier gate. You can select the barrier material from the dropdown list.

iNote

The barrier material may affect the device working. Select a correct barrier material or the barrier may not open.

Lane Length

The width of the lane. You can set the lane width.

iNote

The lane width may affect the device working. Set a correct lane width or the barrier may not open.

Do Not Open Barrier in Authenticates in Lane

If there is someone or something in the lane, the gate will not open even if the credential is authenticated.

This function is designed to avoid more than one person passing through the gate with only one authentication.

Opening/Closing Barrier Speed

Set the barrier's opening and closing speed. You can select from 1 to 10. The greater the value, the faster the speed.

iNote

The recommended value is 6.

4. Click OK.

8.7.2 Configure Device Parameters

After adding the access control device, you can set its parameters such as network parameters.

Set RS-485 Parameters

You can set the access control device's RS-485 parameters including the baud rate, data bit, the stop bit, parity type, flow control type, communication mode, work mode, and connection mode.

Steps

i Note

The RS-485 Settings should be supported by the device.

- 1. Enter the Access Control module.
- **2.** On the navigation bar on the left, enter **Advanced Function** \rightarrow **More Parameters** .
- **3.** Select an access control device in the device list and click **RS-485** to enter the RS-485 Settings page.
- **4.** Select the serial port number from the drop-down list to set the RS-485 parameters.
- **5.** Set the serial number, external device, authentication center, baud rate, data bit, stop bit, parity type, flow control type, communication mode, and working mode in the drop-down list.
- 6. Click Save.
 - The configured parameters will be applied to the device automatically.
 - When you change the working mode or connection mode, the device will reboot automatically.

Enable M1 Card Encryption

M1 card encryption can improve the security level of authentication.

Steps

iNote

The function should be supported by the access control device and the card reader.

- 1. Enter the Access Control module.
- **2.** On the navigation bar on the left, enter **Advanced Function** \rightarrow **More Parameters** .
- **3.** Select an access control device in the device list and click **M1 Card Encryption Verification** to enter the M1 Card Encryption Verification page.
- **4.** Set the switch to on to enable the M1 card encryption function.
- 5. Set the sector ID.

iNote

- The sector ID ranges from 1 to 100.
- By default, Sector 13 is encrypted. It is recommended to encrypt sector 13.

6. Click Save to save the settings.

8.8 Door Control

In Monitoring module, you can view the real-time status of the doors managed by the added access control device. You can also control the doors such as open/close the door, or remain the

door open/closed via the client remotely. The real-time access event are displayed in this module. You can view the access details and person details.

iNote

For the user with door control permission, the user can enter the Monitoring module and control the door. Or the icons used for control will not show. For setting the user permission, refer to *Person Management*.

8.8.1 Control Door Status

You can control the status for the door(s), including unlock door, locking door, remaining the door unlock, remaining the door locked, remain all unlocked, etc.

Before You Start

- Add person and assign access authorization to designed person, and person will have the access authorization to the access points (doors). For details, refer to <u>Person Management</u> and <u>Set</u> <u>Access Group to Assign Access Authorization to Persons</u>.
- Make sure the operation user has the permission of the access points (doors).

Steps

- 1. Click Monitoring to enter the status monitoring page.
- 2. Select an access point group on the upper-right corner.

iNote

For managing the access point group, refer to Group Management.

The doors in the selected access control group will display.

3. Click a door icon to select a door, or press Ctrl and select multiple doors.

iNote

For Remain All Unlocked and Remain All Locked, ignore this step.

4. Click the following buttons to control the door.

Unlock

When the door is locked, unlock it and it will be open for once. After the open duration, the door will be closed and locked again automatically.

Lock

When the door is unlocked, lock it and it will be closed. The person who has the access authorization can access the door with credentials.

Remain Unlocked

The door will be unlocked (no matter closed or open). All the persons can access the door with no credentials required.

Remain Locked

The door will be closed and locked. No person can access the door even if he/she has the authorized credentials, except the super users.

Remain All Unlocked

All doors in the group will be unlocked (no matter closed or open). All the persons can access the doors with no credentials required.

Remain All Locked

All doors in the group will be closed and locked. No person can access the doors even if he/she has the authorized credentials, except the super users.

Capture

Capture a picture manually.

iNote

The **Capture** button is available when the device supports capture function. The picture is saved in the PC running the client. For setting the saving path, refer to *Set File Saving Path* in the user manual of the client software.

Result

The icon of the doors will change in real-time according to the operation if the operation is succeeded.

8.8.2 Check Real-Time Access Records

The real-time access records can be displayed in the client, including card swiping records, face recognition records, skin-surface temperature information, etc. Also, you can view the person information and view the picture captured during access.

Before You Start

You have added person(s) and access control device(s) to the client. For details, refer to <u>Person</u> <u>Management</u> and <u>Add Device</u>.

Steps

1. Click Monitoring to enter monitoring module.

Real-time access records are displayed on the bottom of the page. You can view record details, including card No., person name, event time, door location, temperature, authentication type etc.

Event Type	🗹 Access Even	t 🗹 Other Event	Status 🗹 Nori	mal 🗹 Excep	otion		🗹 Show Latest Eve	nt 💆 Enable Abnormal Temperature Prompt
Card No.	Person Name	Event Time	Door Location	Temperature	Abnormal Temperature	Authentication Type	Person	Linked Capture Picture
-		2020-05-15 17:03:44		36.6°C		Card/Face		
-		2020-05-15 17:03:41	Door1	36.6°C		Card/Face	100 million	
-		2020-05-15 17:03:39	Door1	36.6°C	No	Card/Face		
	-	2020-05-15 17:03:39	101:Dcor1					

Figure 8-4 Real-time Access Records

iNote

You can right click the column name of access event table to show or hide the column according to actual needs.

- **2. Optional:** Select an access point group from the drop-down list in the upper-right corner to show the real time access records of the selected group.
- 3. Optional: Check the event type and event status.

The detected events of checked type and status will be displayed in the list below.

4. Optional: Check Show Latest Event to view the latest access record.

The record list will be listed reverse chronologically.

5. Optional: Check Enable Abnormal Temperature Prompt to enable abnormal skin-surface temperature prompt.

iNote

When enabled, if there is abnormal temperature information, an Abnormal Temperature window pops up when you enter Monitoring module, displaying person's picture, skin-surface temperature, card No., person name, etc.

6. Optional: Click an event to view person pictures (including captured picture and profile).

iNote

In **Linked Capture Picture** field, you can double click the captured picture to view an enlarged picture.

7. Optional: Click **1** to view details (including person's detailed information and the captured picture).

i Note

In the pop-up window, you can click 🔲 to view details in full screen.

Appendix A. DIP Switch

A.1 DIP Switch Description

The DIP switch is on the access control board. No.1 and No 2 is from the low bit to the high bit.




Figure A-1 DIP Switch

When the switch is towards ON, it means the switch is enabled, otherwise, the switch is off.

A.2 DIP Switch Corresponded Functions

iNote

After setting the DIP switch, you should reboot the device, or the function cannot take effect.

The 2-bit DIP switch corresponded functions on the access control board are as follows:

Bit	Device Mode	Function	Decimal Value	DIP Switch Address Diagram
1	Work Mode	Normal Mode	0	
		Study Mode	1	
2	Keyfob Paring Mode	Disable Keyfob Paring Mode	0	
		Enable Keyfob Paring Mode	1	

Appendix B. Button Configuration Description

Refer to the table below for device configuration via button on the main lane control board.

Level-1 Configuration No.	Description	Level-1 Configuration No. and Functions	Notes
2	keyfob Pairing Mode	1-Normal Mode	
		2-Pairing Mode	
		i Note	
		By default, 1 will be	
		displayed on the	
		display screen.	
3	Passing Mode	1-Both sides under	
		control	
		i Note	
		By default, 1 will be	
		displayed on the	
		display screen.	
		2-Entrance under	
		control; exit prohibited	
		3-Entrance under control; exit on	
		inductive mode	
		4-Both sides on	
		inductive mode	
		5-Entrance on	
		inductive mode; exit	
		under control	
		6-Entrance on inductive mode; exit	
		prohibited	
		7-Both sides prohibited	
		8-Entrance prohibited; exit under control	
		9-Entrance prohibited;	
		exit on inductive mode	

Level-1 Configuration No.	Description	Level-1 Configuration No. and Functions	Notes
		10-Entrance under control; exit remaining open	
		11-Entrance under control; exit on free mode	
		12-Entrance on inductive mode; exit remaining open	
		13-Entrance on inductive mode; exit on free mode	
		14-Entrance prohibited; exit remaining open	
		15-Entrance prohibited; exit on free mode	
		16-Entrance remaining open; exit under control	
		17-Entrance remaining open; exit on inductive mode	
		18-Entrance remaining open; exit remaining open	
		19-Entrance remaining open; exit on free mode	
		20-Entrance remaining open; exit prohibited	
		21-Entrance on free mode; exit under control	

Level-1 Configuration No.	Description	Level-1 Configuration No. and Functions	Notes
		22-Entrance on free mode; exit on inductive mode	
		23-Entrance on free mode; exit remaining open	
		24-Entrance on free mode; exit on free mode	
		25-Entrance on free mode; exit prohibited	
4	Memory Mode	1-Disable 2-Enable	
		i Note By default, 2 will be displayed on the display screen.	
5	keyfob Remote Control	1-one to one 2-one to multiple i Note By default, 1 will be displayed on the display screen.	
6	Barrier Opening Speed	1-1, 2-2,10-10 i Note By default, 5 will be displayed on the display screen.	
7	Barrier Closing Speed	1-1, 2-2,10-10	

Level-1 Configuration No.	Description	Level-1 Configuration No. and Functions	Notes
		i Note By default, 5 will be displayed on the display screen.	
8	Card Reading on the Alarm Area	1-Do not open 2-Open i Note By default, 2 will be displayed on the display screen.	
9	Enter Duration	5-5s, 6-6s, 7-7s,, 60- 60s i Note By default, 5 will be displayed on the display screen.	
10	Exit Duration	5-5s, 6-6s, 7-7s,, 60- 60s i Note By default, 5 will be displayed on the display screen.	
11	IR Sensing Duration	0-0s, 1-1s, 2-2s,, 25- 25s i Note By default, 0 will be displayed on the display screen.	
12	Intrusion Duration	0-0s, 1-1s, 2-2s,, 20- 20s	

Level-1 Configuration No.	Description	Level-1 Configuration No. and Functions	Notes
		i Note By default, 0 will be displayed on the display screen.	
13	Overstay Duration	0-0s, 1-1s, 2-2s,, 20- 20s i Note By default, 0 will be displayed on the display screen.	
14	Delay Time for Barrier Closing	0-0s, 1-1s, 2-2s, 3- 3s, 4-4s, 5-5s i Note By default, 0 will be displayed on the display screen.	
15	Control Mode	 1-Button Configuration 2-DIP Switch on Access Control Board i Note By default, 1 will be displayed on the display screen. 	
17	IR Configuration for Closing in Advance	1-1, 2-2,, N-N i Note By default, 1 will be displayed on the display screen.	
18	Lane Number	1-Dual Lanes 2-Single Lane	Unable to change

Level-1 Configuration No.	Description	Level-1 Configuration No. and Functions	Notes
		i Note By default, 1 will be displayed on the display screen.	
19	Motor Rotation	1-Clockwise 2-Anticlockwise i Note By default, 1 will be displayed on the display screen.	Unable to change
21	Volume	1-0, 2-1, 3-2, 4-3, 5-4 i Note By default, 2 will be displayed on the display screen.	The device will be muted when set to "1".
22	Authenticated Passing	1-Disable 2-Enable i Note By default, 1 will be displayed on the display screen.	Unable to change
23	Invalid Card No.	1-Disable 2-Enable INote By default, 1 will be displayed on the display screen.	Unable to change
24	Fingerprint Unmatched	1-Disable 2-Enable	Unable to change

Level-1 Configuration No.	Description	Level-1 Configuration No. and Functions	Notes
		i Note By default, 1 will be displayed on the display screen.	
25	Climbing over Barrier	1-Disable 2-Enable i Note By default, 1 will be displayed on the display screen.	
26	Reverse Passing	1-Disable 2-Enable i Note By default, 1 will be displayed on the display screen.	
27	Exceeding Passing Duration	1-Disable 2-Enable i Note By default, 1 will be displayed on the display screen.	
28	Intrusion Alarm	1-Disable 2-Enable iNote By default, 1 will be displayed on the display screen.	
29	Forced Passing	1-Disable 2-Enable	Unable to change

Level-1 Configuration No.	Description	Level-1 Configuration No. and Functions	Notes
		i Note By default, 1 will be displayed on the display screen.	
30	Tailgating Alarm	1-Disable 2-Enable i Note By default, 1 will be displayed on the display screen.	
31	Unauthorized Passing	1-Disable 2-Enable i Note By default, 1 will be displayed on the display screen.	Unable to change
32	Exceeding Authentication Duration	1-Disable 2-Enable i Note By default, 1 will be displayed on the display screen.	Unable to change
33	Failed Authentication	1-Disable 2-Enable iNote By default, 1 will be displayed on the display screen.	Unable to change
34	Expired Credential	1-Disable 2-Enable	Unable to change

Level-1 Configuration No.	Description	Level-1 Configuration No. and Functions	Notes
		i Note By default, 1 will be displayed on the display screen.	
35	Overstaying Alarm	1-Disable 2-Enable i Note By default, 1 will be displayed on the display screen.	
36	Barrier Material	1-Acrylic	
37	Barrier Length	1-550 2-600 i Note By default, 2 will be displayed on the display screen.	
38	Motor Inspection	 1-Disable 2-Enable on Main Lane 3-Enable on Sub Lane i Note By default, 1 will be displayed on the display screen. 	
39	Brightness of Light	0-0, 1-1, 2-2,, 10- 10 i Note By default, 3 will be displayed on the display screen.	The higher the value is, the brighter the light will be.

Level-1 Configuration No.	Description	Level-1 Configuration No. and Functions	Notes
40	Self-check Voice Prompt	1-Disable 2-Enable i Note By default, 2 will be displayed on the display screen.	Control the device to play the voice prompt of self-check or not.
41	Study Mode Voice Prompt	1-Disable 2-Enable i Note By default, 2 will be displayed on the display screen.	Control the device to play the voice prompt of study mode or not.
42	IR Detector Quantity	4-4, 6-6, 8-8, i Note By default, 4 will be displayed on the display screen.	Unable to change
99	Restore to Default	1- Default 2- Start i Note By default, 1 will be displayed on the display screen.	The device will reboot.

Appendix C. Event and Alarm Type

Event	Alarm Type
Tailgating	Visual and Audible
Reverse Passing	Visual and Audible
Force Accessing	None
Climb over Barrier	Visual and Audible
Overstay	Visual and Audible
Passing Timeout	None
Intrusion	Visual and Audible
Free Passing Authentication Failed	Visual and Audible
Barrier Obstructed	None

Appendix D. Table of Audio Index Related Content

Index	Content
1	Climbing over the barrier.
2	Reverse passing.
3	Passing timeout.
4	Intrusion.
5	Tailgating.
6	Overstay.

Appendix E. Error Code Description

The swing barrier will display the error code on the seven-segment display if error occurred. Refer to the table below to find the description of each number.

Error Reason	Code	Error Reason	Code
The First IR Beam Triggered	01	Not Studying	54
The Second IR Beam Triggered	02	Obstruction	55
The Third IR Beam Triggered	03	Exceeding Studying Range	56
The Fourth IR Beam Triggered	04	Encoder Exception	57
Voice Board Offline	49	Motor Exception	58
If the voice board is not installed, the error code of 49 will be displayed but the device functions normally. Optional Board Not Installed If the optional board is not installed, the error code of 49 will be displayed but the device functions normally.			
Interconnecting Exception	53		

Appendix F. Communication Matrix and Device Command

Communication Matrix

Scan the following QR code to get the device communication matrix. Note that the matrix contains all communication ports of Hikvision access control and video intercom devices.



Figure F-1 QR Code of Communication Matrix

Device Command

Scan the following QR code to get the device common serial port commands. Note that the command list contains all commonly used serial ports commands for all Hikvision access control and video intercom devices.



Figure F-2 Device Command

