# HIKVISION

## HF-VT344
## Fire Detection Camera

Quick Start Guide

## Product Information

Read all information and instructions in this document carefully before using the device and keep it for further reference.
For more device information and instructions, please visit our website at https://www.hikvision.com. You can also refer to other documents (if any) accompanying the device or scan the QR code (if any) on the packaging to get more information.

**About this Document**
• This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
• The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of the Document at the Hikvision website (https://www.hikvision.com). Unless otherwise agreed, Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as "Hikvision") makes no warranties, express or implied.
• Please use the Document with the guidance and assistance of professionals trained in supporting the Product.

**About this Product**
This product can only enjoy the after-sales service support in the country or region where the purchase is made.

**Acknowledgment of Intellectual Property Rights**
• Hikvision owns the copyrights and/or patents related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties.
• Any part of the Document, including text, pictures, graphics, etc., belongs to Hikvision. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.
• HIKVISION and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.
• Other trademarks and logos mentioned are the properties of their respective owners.

**LEGAL DISCLAIMER**
• TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS DOCUMENT AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.
• YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.
• YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END- USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.
• IN THE EVENT OF ANY CONFLICTS BETWEEN THIS DOCUMENT AND THE APPLICABLE LAW, THE LATTER PREVAILS.

© Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.

⚠️
1. CAUTION: Risk of explosion if the battery is replaced by an incorrect type.
2. Improper replacement of the battery with an incorrect type may defeat a safeguard (for example, in the case of some lithium battery types).
3. Do not dispose of the battery into fire or a hot oven, or mechanically crush or cut the battery, which may result in an explosion.
4. Do not leave the battery in an extremely high temperature surrounding environment, which may result in an explosion or the leakage of flammable liquid or gas.
5. Do not subject the battery to extremely low air pressure, which may result in an explosion or the leakage of flammable liquid or gas.
6. Dispose of used batteries according to the instructions.

---

# English

## Diagram Reference

### 1 Cautions

- In the use of the product, you must be in strict compliance with the electrical safety regulations of the nation and region.
- Correctly install and maintain the camera. Although camera can help save lives by providing an early warning of a fire, they are not a substitute for an insurance policy. Home owners should have adequate insurance to protect their lives and properties.
- The camera is only suitable for safe use in areas below 2000 m above sea level and under non tropical conditions.
- The camera has multiple power supplies. Please disconnect all power supplies during maintenance.
- According to relevant national standards, when supplying power to weak current equipment, the power supply current shall not exceed 8 A and the power shall not exceed 100 W to prevent safety accidents.
- If it is necessary to use it in special environment (such as peak, iron tower, forest, etc.), please add lightning arrester at the equipment inlet.
- Do not aim the lens at strong light (such as light illumination, sunlight or laser beam, etc.), otherwise the image sensor will be damaged.
- Do not touch the image sensor directly. If it is necessary to clean it, please slightly wet the soft and clean cloth with alcohol and gently wipe away the dust; When the product is not used, please add the dust cover to protect the image sensor.
- To ensure the normal detection of the camera, do not use hair spray, insecticide, diluent and other substances that can produce colloidal suspension near the alarm.
- No naked flame sources, such as lighted candles, should be placed on the equipment.
- The product is a flame, which can send out audible and visual alarm signals in the event of fire, but cannot extinguish fire.
- Do not be at high volume for a long time near to the ears to prevent hearing impairment.
- Keep the packing so that in case of any problem, pack the alarm in its original packing and send it to the agent or return it to the factory for disposal.
- If the camera does not work properly, contact the dealer or the nearest service center. Never attempt to disassemble the camera yourself. (We shall not assume any responsibility for problems caused by unauthorized repair or maintenance.)

### 2 Appearance

1. Speaker
2. MicroSD Slot
3. RESET Button
4. Debug UART
5. Visible Camera
6. Thermal Imaging Camera
7. Sun Shade
8. Flash
9. Microphone
10. Indicator

### 3 Interface and Wiring

#### A. Interface

1. 4 ~ 20 mA Interface
2. RS-485 Interface
3. Power Input Interface
4. Network Interface
5. Alarm Interface
6. Audio Output Interface
7. Audio Input Interface

#### B. Wiring

a. Pull off the green plug on the connector.
b. Turn the micro slotted screwdriver counterclockwise to loosen the screw, place the cable and tighten the screw.
c. After wiring, clip the plug into the corresponding green socket.

**Alarm Interface**

| No. | Sign | Wiring Instruction |
|---|---|---|
| 1 | IN1 | Alarm Input Device 1+ |
| 3 | GND | Alarm Input Device 1- |
| 2 | IN2 | Alarm Input Device 2+ |
| 3 | GND | Alarm Input Device 2- |
| 4 | OUT1A | Alarm Output Device 1 |
| 5 | OUT1B | |
| 6 | OUT2A | Alarm Output Device 2 |
| 7 | OUT2B | |

**RS-485 Interface**

| No. | Sign | Wiring Instruction |
|---|---|---|
| 1 | D- | RS-485 Signal B |
| 2 | D+ | RS-485 Signal A |

**Power Output Interface**

| No. | Sign | Wiring Instruction |
|---|---|---|
| 1 | L- | Current Output - |
| 2 | L+ | Current Output + |

**Power Input Interface**

| No. | Sign | Wiring Instruction |
|---|---|---|
| 1 | + | Power Input Positive Pole |
| 2 | ⏚ | Power Grounding |
| 3 | - | Power Input Negative Pole |

### 4 LED Indicator & Speaker

| Device Status | LED Indicator | Speaker |
|---|---|---|
| Flame/Smoke Alarm | The red LED is on. | Di...Di...Di... |
| Normal | The green LED is on. | / |
| Fault | The yellow LED is on. | / |
| Abnormal Temperature Alarm | The red LED is on. | Di...Di...Di... |
| Detector is masked. | / | Di...Di...Di... |
| Exception | / | Di...Di...Di... |

### 5 Installation

#### A. Notification

• Install the camera according to the instructions in this guide.
• To prevent injury, the camera must be securely attached to the floor/wall in accordance with the installed instructions.
• Before installation, confirm that the camera and other mounting parts in the box are in good condition.
• Do not install the camera in new or renovated buildings until all work is completed. The installation wall shall be able to bear at least 4 times the total weight of the camera and installation accessories.
• Install multiple alarms if the installation location (such as ceiling) is longer than 32.81 ft (10 meters).
• For bracket installation, please pay attention to the bearing indications on the mounting bracket.
• If it is installed on the cement wall, first install the expansion bolt and then install the bracket. If on the wooden wall, directly install bracket with tapping screws.
• Please install the waterproof tape and the mesh waterproof package according to the specifications. For the specific installation method, please refer to the user manual.
• When moving the camera, do not directly pull the cable at the tail of the camera, or it may affect the waterproof performance or cause imaging problems.

---

### B. Mounting Locations
### C. Installation Method

**Note: After installation, it can be adjusted from 0 to 360 degrees horizontally, from -45 to 45 degrees vertically.**

### 6 Features

**Activate Camera**
When powered on for the first time, the detector must be activated before normal use.
IP address: 192.168.1.64
1. Connect the camera and the computer with network cable, and modify the computer IP address and detector IP address in the same network segment.
2. Power on the detector.
3. Enter 192.168.1.64 in the browser to enter the detector webpage, and create the admin password.
4. Click **OK** for activation.

**Configure and Operate via web**
In the browser address bar, enter 192.168.1.64 and log in to the detector webpage. Please scan the QR code in the last part of this guide for detailed user manual.

**Measure Temperature**
It is used to measure the temperature of the site in real time. When a target triggers the configured temperature measurement rules, it will measure the temperature and give an alarm.

**Reset**
Press and hold reset button for 10 to 15 seconds when it is energized, all the parameters of the detector will be restored to the factory settings.

**Fire/Smoke Detection**
Configure and enable the smoke and fire detection function on the device's web page. When smoke or flames are detected and an alarm is triggered, the device will broadcast a voice alarm prompt and trigger the configured linkage action.

### 7 Specification

**Camera**

| | |
|---|---|
| Max. Image Size | 2560 × 1440 |
| Sensor Type | 1/3" Progressive Scan CMOS |
| Main Stream | 50Hz: 25 fps (2560 × 1440, 1920 × 1080, 1280 × 720)<br>60Hz: 30 fps (2560 × 1440, 1920 × 1080, 1280 × 720) |
| Max. Resolution | Max. effective resolution : 256 × 192; Encoding resolution: 1280 × 720 |
| Sub Stream | 50Hz: 25 fps (704 × 576, 640 × 480, 352 × 288)<br>60Hz: 30 fps (704 × 480, 640 × 480, 352 × 240) |
| Min. Illumination | Color: 0.01 Lux @（F1.6，AGC ON） |
| Lens | Horizontal: 78.96°, Vertical: 43.17°, Diagonal: 93.31° |
| Image Settings | Saturation, brightness, contrast, sharpness, AGC and white balance can be adjusted through the client or browser. |
| WDR | WDR |
| Shutter | 1/25 ~ 1/100,000 s |
| Image Enhancement | BLC, 3D DNR |
| Main Stream Video Compression Standard | H.265, H.264 |
| Sub Stream Compression Standard | H.265, H.264 |
| Video Bitrate | 256 Kbps ~ 8192 Kbps |
| Intelligent Alarm | Intrusion detection, line crossing detection, smoke and flame detection |
| Protocol | TCP/IP, HTTP, HTTPS, DHCP, DNS, RTP, RTSP, RTCP, NTP, IPv4, UDP |
| Interface Protocol | ONVIF(PROFILE S, PROFILE G), ISAPI，EZVIZ |
| General | Anti flicker, heartbeat, image, password protection, video occlusion |
| Storage | Micro SD/SDHC/SDXC card (256 G) disconnection local storage |
| Exception Detection | Motion Detection, video tampering alarm, network cable disconnection, IP address conflict, invalid access, full memory, memory error |
| WEB Configuration | Support web preview, configuration and parameter import/export |
| Power Consumption | ＜10 W |
| IR Range | 10 m |
| Accessory Type | Wall mounted support, pendent support, universal joint |

**Detector**

| | |
|---|---|
| Image Sensor | Vanadium Oxide (VOx) Microbolometer |
| Pixel Size | 12 μm |
| Response Waveband | 8 ~ 14 μm |
| Focal Length of Thermal Imaging Lens | 3.2 mm |
| Thermal Imaging Field of View | 56.2° × 42.2° |
| Palette Mode | Support 15 modes including white hot, black hot, fusion 1, rainbow, fusion 2, iron red 1, iron red 2, etc. |
| Fire and Smoke Detection | Yes |
| Temperature Exception Detection | Yes |
| Temperature Measurement Range | -20 °C ~ 400 °C |
| Thermography Precision | Max (± 8 °C, ± 8 %) , within the range of 0.4 ~ 2.5 m from the device |
| Noise Equivalent Temperature Difference (NETD) | ≤50 mK (@25 °C,F1.0) |
| Temperature Sensing Mode | Support non-contact temperature sensing |
| High Temperature Alarm | Yes |
| Alarm Indicator Light | Red: Alarm<br>Green: Normal<br>Yellow: Fault |

---

**Interface**

| Interface | |
|---|---|
| Alarm Interface | 2 way alarm input (Alarm in), 2 way alarm output (Alarm out, support DC 30 V/2 or AC 125 V/0.5 A) |
| Ethernet Interface | RJ45 10 M/100 M adaptive Ethernet port × 1 |
| Audio Interface | 1 way audio input (Line in), 1 way audio output (Line out), 1 way built-in microphone, 1 way built-in speaker |
| **Professional Intelligence (Deep Learning Algorithm)** | |
| Flame Detection | Yes |
| Smoke Detection | Yes |
| **General** | |
| Ingress Protection | IP 66 |
| Mounting Height | Indoor: higher than 2.5 m<br>Outdoor: higher than 3.5 m |
| Power Interface Type | 3pin industrial terminal, spacing: 3.81 |
| Power | DC 10V ~ DC 36V, 24W MAX; PoE: 802.3at; CLASS 4 (The power adapter is not included; you will need to configure it yourself) |
| Working Temperature | -20 ~ 60 °C |
| Working Humidity | ＜95% RH |
| Product Implementation Standard | Q/HKD 054-2024 |
| Weight | 1.4 kg (without packaging), 1.7 kg (with packaging) |
| Dimension (L × W × H) | 212.5 × 130.0 × 84.8 mm |

---

### 2

212.5 mm

130.0 mm

84.8 mm

### 3

**A**

### 5

**B**

## Identify Flame

33×33 cm
Area of Flame

≤30 m

---

## Identify Smoke

Occupied Area of Smoke in the Picture > 5%

1080 p

### 5

**C**

Screw

microSD Card

4× (PA4 × 25)

Location

2 × (1/4-20 UNC × 12)

-45°~ 45°

0°~ 360°

Scan the QR code for user manual.

---