



DS-K3G200(L)X Series Tripod Turnstile Video Guide



Contents

1 Unboxing	1
2 Arm Installation	1
3 Access Board	1
4 1100&1102 Series Card Reader	1
5 RS-485 Card Reader and QR Code Scanner	1
6 Main Switch	1
7 Face Recognition Terminal	1

1 Unboxing

Refer to the unboxing video for details:

Refer to the link to see the high-definition video: <https://enpinfodata.hikvision.com/analysisQR/showQR/b5e8fa62>

2 Arm Installation

Refer to the arm installation video for details:

Refer to the link to see the high-definition video: <https://enpinfodata.hikvision.com/analysisQR/showQR/991e449c>

3 Access Board

Refer to the access board installation and wiring video for details:

Refer to the link to see the high-definition video: <https://enpinfodata.hikvision.com/analysisQR/showQR/1bb58924>

4 1100&1102 Series Card Reader

Refer to the 1100&1102 series card reader installation and wiring video for details:

Refer to the link to see the high-definition video: <https://enpinfodata.hikvision.com/analysisQR/showQR/d776c4d3>

5 RS-485 Card Reader and QR Code Scanner

Refer to the RS-485 card reader and QR code scanner installation and wiring video for details:

Refer to the link to see the high-definition video: <https://enpinfodata.hikvision.com/analysisQR/showQR/dd3b0096>

6 Main Switch

Refer to the main switch wiring video for details:

Refer to the link to see the high-definition video: <https://enpinfodata.hikvision.com/analysisQR/showQR/23a7a8eb>

7 Face Recognition Terminal

Refer to the face recognition terminal wiring video for details:

Refer to the link to see the high-definition video: **[https://
enpinfodata.hikvision.com/analysisQR/showQR/51b98684](https://enpinfodata.hikvision.com/analysisQR/showQR/51b98684)**