# DS-PDMCS-EG2-WE(B)/DS-PDMCS-EG2-WB(B) **Wireless Slim Magnet Detector**

**HIKVISION** 

EN 50131-5-3:2017

UD38170B

- out this Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
  This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
  The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of the Document at the Hikvision website (https://www.hikvision.com).
  Unless otherwise agreed, Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter incred to as "Hilbidoon") makes no warranties, express or implied.
  Please use the Document with the guidance and assistance of professionals trained in supporting the Product.

• This product can only enjoy the after-sales service support in the country or region where the purchase is made.
• If the product you choose is a video product, please scan the following QR code to obtain the "Initiatives on the Use of Video Products", and read it carefully.

- Acknowledgment of Intellectual Property Rights

   Hikivision owns the copyrights and/or patients related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties.

   Any part of the Document, including text, pictures, graphics, etc., belongs to Hikivision. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.

   If WYS/IOV and other Hikivision's trademarks and logos are the properties of Hikivision in various jurisdictions.

   Other trademarks and logos mentioned are the properties of their respective owners.

LEGAL DECLAMBER

\*\*O THE MANUMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS DOCUMENT AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIRVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITIATION, MECHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS A YOUR OWN RISK. IN TO EVENT WILL HIRVISION BE LIBBLE TO YOU FOR ANY SPECIAL, CONSCIUENTIAL, INCLUDENTIAL, INCLUDING WITHOUT CHARLEST AND AND SEAL OF THE PROPRIET SECURITY RISKS, AND HIRK VIEW OF THE PROPRIET SECURITY RISKS, AND HIRK VIEW OF THE PROPRIET SECURITY RISKS. HOWEVER, HIRVISION WILL PROVIDE TIME VIEW OF THE PROPRIET SECURITY RISKS. HOWEVER, HIRVISION WILL PROVIDE TIME VIEW OF THE PROPRIET SECURITY RISKS. HOWEVER, HIRVISION WILL PROVIDE TIME VIEW OF THE PROPRIET SECURITY RISKS. HOWEVER, HIRVISION WILL PROVIDE TIME VIEW OF THE PROPRIET SECURITY RISKS. HOWEVER, HIRVISION WILL PROVIDE TIME VIEW OF THE PROPRIET SECURITY RISKS. HOWEVER, HIRVISION WILL PROVIDE TIME VIEW OF THE PROPRIET SECURITY RISKS. HOWEVER, HIRVISION WILL PROVIDE TIME VIEW OF THE PROPRIET SECURITY RISKS. HOWEVER, HIRVISION WILL PROVIDE TIME VIEW OF THE PROPRIET SECURITY RISKS. HOWEVER, HIRVISION WILL PROVIDE TIME VIEW OF THE PROPRIET SECURITY RISKS. HOWEVER, HIRVISION WILL PROVIDE TIME VIEW OF THE PROPRIET SECURITY R


- All rights reserved.

#### 1 Introduction

The sensor can detect the door or window opening. When the door or window is open, an alarm will be triggered and it will be sent to the alarm center or mobile client via security control panel.

Door Magnetic Sensor Alarm: When the distance between the sensor and the magnetic stick is longer than 3 cm, an alarm will be triggered. The indicator will flash once. Tamper Alarm: When removing the sensor, an alarm will be triggered.

## 2 Appearance



#### CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TIFE. REPLACEMENT OF A BATTERY WITH AN INCORRECT TYPE THAT CAN DEFEAT A SAFEGUARD.

#### CAUTION

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS AND LOCAL REGULATION.

#### CAUTION

CHEMICAL BURNING DANGER DO NOT SWALLOW THE BATTERY KEEP NEW AND USED BATTERIES AWAY FROM THE


IF YOU THINK BATTERIES MIGHT HAVE BEEN SWALLOWED OR PLACED INSIDE ANY PART OF THE BODY, SEEK IMMEDIATE MEDICAL ATTENTION.

- Magnetic Stick
- (2) Positioning Line
- Indicator

Alarm Detection: Red LED flashes. Detector Formatted: Red LED flashes 3 times.

- (4) TAMPER Button Tampering Alarm: If the detector is disassembled, an alarm will be triggered.
  - Formatting: Restore the device to default settings.
- (5) Power Switch
- 6 Battery

## 3 Power On



#### **CAUTION**

IF THE BATTERY COMPARTMENT DOES NOT CLOSE SECURELY, STOP USING THE PRODUCT AND KEEP IT AWAY FROM CHILDREN.

Dig the groove to disassemble the device. Remove the front and rear panel. Turn the power switch to ON to power on the device. Note: Do not disassemble the device with sharps


#### 4 Enrollment

- 1. Log in to the APP Store, download and install App.
- 2. Power on the security control panel.
  3. Log in the APP and tap the icon "+" . Scan the QR code or input the control panel serial No. to add the control panel.

#### 1 Enroll the Peripheral Locally

- 1. In the APP, tap the "Enrollment Mode" button on the control panel page to make the control panel enter the enrollment status.

  2. Power on the peripheral, and it will be automatically enrolled to the control panel.
- 2 Enroll the Peripheral with QR and serial No.
- 1. In the APP, tap the icon "+"and scan the QR code or serial No. on the peripheral.
  2. Power on the peripheral, and it will be automatically enrolled to the control panel.




## 5 Test

The contact starts test automatically after being enrolled to the AX PRO. The LED turn red.

Separate the contact, and make a gap between the sensor and stick. while the LED turns green, the alarm is triggered by this gap . Adjust the installation position of the contact to get a satisfied alarm gap.


The alarm will be triggered while the gap between the sensor and magnetic stick is bigger than that shows in the table. The LED keeps blue for 2 s. Magnet Detection Performance Table

Axes of	Event	On non-ferromagnetic	On ferromagnetic
Operation	Event	material surface	material surface
X+	Break	84	21
	Make	78	20
X-	Break	65	9
	Make	61	8
Υ	Break	50	10
	Make	36	8
Z+	Break	52	11
	Make	47	9
Z-	Break	52	12
	Make	48	9



## 6 Installation

1. Check Signal Strength
Enter the signal checking mode by operating on the control panel. Trigger the detector.
Solid Green for 3 s - Strong Signal
Solid Orange for 3 s - Medium Signal
Solid Red for 3 s - Weak Signal
Red light flashes for 3S - Lost Signal




2. Install the Detector
a. Dig the groove to disassemble the device.
Method 1: Secure the rear panel to the wall with two screws.
Method 2: Paste rear panel on the wall with the sponge tape.


Note: To make the TAMPER work properly, the thickness of the sponge tape should be no more than 1mm. Installing with sponge tape is non EN compliant.

b. Close the front and the rear panel.

Note: You should install the sensor and the magnetic stick at the door or window's edge. Make sure they are aligned with the door or window's edge.



Align the Positioning Line



Method 1. Method 2. 3

### 7 Formatting

- 1. Remove the battery.
- 2. Hold the TAMPER button and power the detector on at the same time.
- The red LED flashes 3 time when the formatting is completed.

### 8 Set Up with App

You can view the device status including temperature, signal intensity, battery level, lid, magnetic contact, etc.,on the device page. Tap the  $\mathbf{o}$  button to enter the settings page.

Disallowed field adjustable settings: None

Function	Description
Zone Type	Select the zone type of the detector.
Stay Arm Bypass	Slide to green to bypass the zone from stay arming.
Chime	Slide to green to enable the chime.
Enable Silent Zone	Slide to green to make the zone keep silent while alarm is triggered.
Double Knock	Slide to green to make the zone alarm with double knock.
Cross Zone	If the alarm triggered in both of the linked zones within the set time, two alarm messages will be reported.
Link Camera	Link with a camera for intruder verification.
LED	Turn On/Off the LED.
Polling Rate	Set the interval of heartbeat.
Signal Strength Test	Enter the test mode, and view the LED indication.
Detection Zone Test	Enter the test mode, separate the contact, and start the test with Magnet Detection Performance Table.
Zone Bypass	By pass the zone.

### 9 Operation Caution and Device Maintenance

- All the electronic operation should be strictly compliance with the electrical safety regulations, fire prevention regulations and other related regulations in your local region.
- Do not drop the device or subject it to physical shock, and do not expose it to high electromagnetism radiation. Avoid the equipment installation on vibrations surface or places subject to shock (ignorance can cause equipment damage).
- Please make sure that the power has been disconnected before you wire, install or dismantle the device.
- If smoke, odors or noise rise from the device, turn off the power at once and unplug the power cable, and then please contact the service center.
- Do not drop the device or subject it to physical shock, and do not expose it to high electromagnetism radiation. Avoid the equipment installation on vibrations surface or places subject to shock (ignorance can cause equipment damage).
- Do not place the device in extremely hot (refer to the specification of the device for the detailed operation temperature), cold, dusty or damp locations, and do not expose it to high electromagnetic radiation.
- The device for indoor use shall be kept from rain and moisture.
- Exposing the equipment to direct sun light, low ventilation or heat source such as heater or radiator is forbidden (ignorance can cause fire danger).
- Do not aim the device at the sun or extra bright places. A blooming or smear may occur otherwise (which is not a malfunction however), and affecting the endurance of sensor at the same time.
- Improper use or replacement of the battery may result in hazard of explosion. Replace with the same or equivalent type only. Dispose of used batteries according to the instructions provided by the battery manufacturer.
- Do not expose the device to the corrosive gas. Otherwise the equipment damage may occur.
- Do not expose the device to the explosive situation.



Model		DS-PDMCS-EG2-WE(B)/WB(B)	
Detection	Detection Method	Opening Contact	
Performance	Detection Gap	52mm Max	
Feature	Digital Processing	Support	
	Tamper Protection	Rear	
	Environment Temperature Indicator	Support	
	Signal Strength Indicator	Support	
Interface	Power Switch	Power Up Enrolling	
	LED Indicator	Blue (Alarm)	
Transmission	Transmission Technology	Tri-X Wireless	
	Transmission Method	Two-Way RF Wireless	
	Transmission Frequency	433/868MHz	
	Transmission Security	AES-128 Encryption	
	Transmission Range(Free Space)	0.8 Km(433MHz)/1.2 Km(868MHz)	
	Frequency Hopping	Support	
	Enrolling Method	Power up,Remote ID,QR Code	
Electrical Characteristics	Power Supply	Battery Powered	
	Battery Type	CR2450 x 1 (included), 3V/620mA	
	Typical Voltage	3V	
	Communication	Max. current: 40 mA	
	Consumption	Quiescent current: 24µA	
	Low Battery Level	2.55 V	
	Standard Battery Life	3 Years	
General	Operation Temperature	-10 °C to 55 °C (14 °F to 131 °F)	
	Storage Temperature	-20 °C to 60 °C (-4 °F to 140 °F)	
	Operation Humidity	10% to 90%	
	Dimension(WxHxD)	29mm × 69mm × 10mm 14mm × 69mm × 10mm	
	Weight	38g	
	Application Scenario	Indoor	