

HIKVISION

Wireless Double PIR Camera Detector


Quick Start Guide

For DS-PDPC18-HM-WE/DS-PDPC18-HM-WEUHK:
EN 50131-1:2006+A3:2020
EN 50131-2-2:2021
EN 50131-5-3:2017
EN 50131-6:2017+A1:2021
Security Grade 2
Environment Class IV

UD36766B-A




Step 1. Scan to download the Hik-Connect or Hik-Partner Pro App, and enroll the control panel.



Step 2. Tap the control panel on the home page. Tap **Device** → **Add Device** → **Scan OR Code** to enroll the device.



Step 3. Adjust the knob to the unlock icon, and press the button to remove the rear cover and the middle frame.



Step 4. Install 4 batteries into the device, and turn on the power switch.

User Manual

